

# Reactor<sup>®</sup> E-10hp

332144G

EN

For spraying or dispensing polyurea coatings and polyurethane foam. For professional use only.

**Not approved for use in explosive atmospheres or hazardous locations.**


*3000 psi (21 MPa, 207 bar) Maximum Working Pressure*

For model information, see page 9.



### **Important Safety Instructions**

Read all warnings and instructions in this manual. Save these instructions.








# Contents

|   |           |  |           |
|---|-----------|--|-----------|
| <b>Warnings</b> .....                               | <b>3</b>  | <b>Troubleshooting</b> .....             | <b>28</b> |
| <b>Important Isocyanate (ISO) Information</b> ..... | <b>6</b>  | Pump Control Status Codes .....          | 28        |
| Material Self-ignition .....                        | 7         | DIP Switch Settings .....                | 30        |
| Keep Components A and B Separate .....              | 7         | Heat Control Diagnostic Codes .....      | 32        |
| Moisture Sensitivity of Isocyanates .....           | 7         | Reactor Electronics .....                | 34        |
| Foam Resins with 245 fa Blowing Agents .....        | 8         | Heaters .....                            | 36        |
| Changing Materials .....                            | 8         | Proportioner .....                       | 37        |
| <b>Systems</b> .....                                | <b>9</b>  | <b>Repair</b> .....                      | <b>40</b> |
| <b>Models</b> .....                                 | <b>9</b>  | Before Beginning Repair .....            | 40        |
| <b>Related Manuals</b> .....                        | <b>10</b> | Remove Supply Tank .....                 | 40        |
| <b>Overview</b> .....                               | <b>11</b> | Replace Recirc/Spray Valves .....        | 41        |
| <b>Component Identification</b> .....               | <b>12</b> | Displacement Pump .....                  | 42        |
| <b>Controls and Indicators</b> .....                | <b>13</b> | Control Panel .....                      | 43        |
| Heater Controls .....                               | 13        | Motor Control .....                      | 45        |
| System Controls .....                               | 13        | Heater .....                             | 49        |
| Controls and Indicators .....                       | 14        | Pressure Transducers .....               | 51        |
| <b>Setup</b> .....                                  | <b>16</b> | Drive Housing .....                      | 52        |
| Locate Reactor .....                                | 16        | Replace Cycle Counter Switch .....       | 53        |
| Electrical Requirements .....                       | 16        | Electric Motor .....                     | 54        |
| Ground System .....                                 | 17        | Motor Brushes .....                      | 55        |
| Connect Fluid Hoses .....                           | 17        | Fans .....                               | 55        |
| Connect Gun Air Hose .....                          | 17        | Tank Fluid Level Sensors .....           | 56        |
| Connect Main Air Supply .....                       | 17        | <b>Parts</b> .....                       | <b>58</b> |
| Flush Before First Use .....                        | 17        | System Packages .....                    | 58        |
| Fill Wet-Cups .....                                 | 18        | E-10hp Proportioners .....               | 59        |
| Fill Fluid Tanks .....                              | 18        | <b>Suggested Replacement Parts</b> ..... | <b>75</b> |
| Purge Air and Flush Fluid From Lines .....          | 19        | <b>Accessories</b> .....                 | <b>75</b> |
| <b>Startup</b> .....                                | <b>20</b> | <b>Dimensions</b> .....                  | <b>75</b> |
| Heatup Guidelines .....                             | 21        | <b>Technical Data</b> .....              | <b>76</b> |
| Heat Management Tips .....                          | 21        | <b>Graco Standard Warranty</b> .....     | <b>78</b> |
| <b>Spraying</b> .....                               | <b>22</b> |  |           |
| <b>Pause</b> .....                                  | <b>23</b> |  |           |
| <b>Refill Tanks</b> .....                           | <b>23</b> |  |           |
| <b>Pressure Relief Procedure</b> .....              | <b>24</b> |  |           |
| <b>Shutdown</b> .....                               | <b>24</b> |  |           |
| <b>Maintenance</b> .....                            | <b>25</b> |  |           |
| <b>Flushing</b> .....                               | <b>26</b> |  |           |
| Purge Hoses .....                                   | 27        |  |           |












# Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbols refer to procedure-specific risks. When these symbols appear in the body of this manual or on warning labels, refer back to these Warnings. Product-specific hazard symbols and warnings not covered in this section may appear throughout the body of this manual where applicable.

|  <h2 style="margin: 0;">WARNING</h2>  |   |
|--|---|
| <br><br> | <p><b>ELECTRIC SHOCK HAZARD</b></p> <p>This equipment must be grounded. Improper grounding, setup, or usage of the system can cause electric shock.</p> <ul style="list-style-type: none"> <li>• Turn off and disconnect power cord before servicing equipment.</li> <li>• Connect only to grounded electrical outlets.</li> <li>• Use only 3-wire extension cords.</li> <li>• Ensure ground prongs are intact on power and extension cords.</li> <li>• Do not expose to rain. Store indoors.</li> </ul>  |
|    | <p><b>TOXIC FLUID OR FUMES HAZARD</b></p> <p>Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled or swallowed.</p> <ul style="list-style-type: none"> <li>• Read Safety Data Sheet (SDS) for handling instructions and to know the specific hazards of the fluids you are using, including the effects of long-term exposure.</li> <li>• When spraying, servicing equipment, or when in the work area, always keep work area well ventilated and always wear appropriate personal protective equipment. See <b>Personal Protective Equipment</b> warnings in this manual.</li> <li>• Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines.</li> </ul> |
|   | <p><b>PERSONAL PROTECTIVE EQUIPMENT</b></p> <p>Always wear appropriate protective equipment and cover all skin when spraying, servicing equipment, or when in the work area. Protective equipment helps serious injury, including long-term exposure; inhalation of toxic fumes, mists or vapors; allergic reaction; burns; eye injury and hearing loss. This protective equipment includes but is not limited to:</p> <ul style="list-style-type: none"> <li>• A properly fitting respirator, which may include a supplied-air respirator, chemically impermeable gloves, protective clothing and foot coverings as recommended by the fluid manufacturer and local regulatory authority.</li> <li>• Protective and hearing protection.</li> </ul> |








# WARNING

|  |   |
|--|---|
|     | <p><b>SKIN INJECTION HAZARD</b></p> <p>High-pressure fluid from gun, hose leaks, or ruptured components will pierce skin. This may look like just a cut, but it is a serious injury that can result in amputation. <b>Get immediate surgical treatment.</b></p> <ul style="list-style-type: none"> <li>• Engage trigger lock when not spraying.</li> <li>• Do not point gun at anyone or at any part of the body.</li> <li>• Do not put your hand over the spray tip.</li> <li>• Do not stop or deflect leaks with your hand, body, glove, or rag.</li> <li>• Follow the <b>Pressure Relief Procedure</b> when you stop spraying and before cleaning, checking, or servicing equipment.</li> <li>• Tighten all fluid connections before operating the equipment.</li> <li>• Check hoses and couplings daily. Replace worn or damaged parts immediately.</li> </ul>  |
|     | <p><b>FIRE AND EXPLOSION HAZARD</b></p> <p>Flammable fumes, such as solvent and paint fumes, in <b>work area</b> can ignite or explode. To help prevent fire and explosion:</p> <ul style="list-style-type: none"> <li>• Use equipment only in well ventilated area.</li> <li>• Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static arc).</li> <li>• Keep work area free of debris, including solvent, rags and gasoline.</li> <li>• Do not plug or unplug power cords, or turn power or light switches on or off when flammable fumes are present.</li> <li>• Ground all equipment in the work area. See <b>Grounding</b> instructions.</li> <li>• Use only grounded hoses.</li> <li>• Hold gun firmly to side of grounded pail when triggering into pail. Do not use pail liners unless they are antistatic or conductive.</li> <li>• <b>Stop operation immediately</b> if static sparking occurs or you feel a shock. Do not use equipment until you identify and correct the problem.</li> <li>• Keep a working fire extinguisher in the work area.</li> </ul> |
|     | <p><b>THERMAL EXPANSION HAZARD</b></p> <p>Fluids subjected to heat in confined spaces, including hoses, can create a rapid rise in pressure due to the thermal expansion. Over-pressurization can result in equipment rupture and serious injury.</p> <ul style="list-style-type: none"> <li>• Open a valve to relieve the fluid expansion during heating.</li> <li>• Replace hoses proactively at regular intervals based on your operating conditions.</li> </ul>   |
|   | <p><b>PRESSURIZED ALUMINUM PARTS HAZARD</b></p> <p>Use of fluids that are incompatible with aluminum in pressurized equipment can cause serious chemical reaction and equipment rupture. Failure to follow this warning can result in death, serious injury, or property damage.</p> <ul style="list-style-type: none"> <li>• Do not use 1,1,1-trichloroethane, methylene chloride, other halogenated hydrocarbon solvents or fluids containing such solvents.</li> <li>• Many other fluids may contain chemicals that can react with aluminum. Contact your material supplier for compatibility.</li> </ul>  |




# WARNING

|   |  |
|---|--|
|       | <p><b>EQUIPMENT MISUSE HAZARD</b></p> <p>Misuse can cause death or serious injury.</p> <ul style="list-style-type: none"> <li>• Do not operate the unit when fatigued or under the influence of drugs or alcohol.</li> <li>• Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See <b>Technical Data</b> in all equipment manuals.</li> <li>• Use fluids and solvents that are compatible with equipment wetted parts. See Technical Data in all equipment manuals. Read fluid and solvent manufacturer's warnings. For complete information about your material, request MSDS from distributor or retailer.</li> <li>• Do not leave the work area while equipment is energized or under pressure.</li> <li>• Turn off all equipment and follow the <b>Pressure Relief Procedure</b> when equipment is not in use.</li> <li>• Check equipment daily. Repair or replace worn or damaged parts immediately with genuine manufacturer's replacement parts only.</li> <li>• Do not alter or modify equipment. Alterations or modifications may void agency approvals and create safety hazards.</li> <li>• Make sure all equipment is rated and approved for the environment in which you are using it.</li> <li>• Use equipment only for its intended purpose. Call your distributor for information.</li> <li>• Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces.</li> <li>• Do not kink or over bend hoses or use hoses to pull equipment.</li> <li>• Keep children and animals away from work area.</li> <li>• Comply with all applicable safety regulations.</li> </ul> |
|   | <p><b>MOVING PARTS HAZARD</b></p> <p>Moving parts can pinch, cut or amputate fingers and other body parts.</p> <ul style="list-style-type: none"> <li>• Keep clear of moving parts.</li> <li>• Do not operate equipment with protective guards or covers removed.</li> <li>• Pressurized equipment can start without warning. Before checking, moving, or servicing equipment, follow the <b>Pressure Relief Procedure</b> and disconnect all power sources.</li> </ul>  |
|    | <p><b>BURN HAZARD</b></p> <p>Equipment surfaces and fluid that's heated can become very hot during operation. To avoid severe burns:</p> <ul style="list-style-type: none"> <li>• Do not touch hot fluid or equipment.</li> </ul>  |

# Important Isocyanate (ISO) Information


Isocyanates (ISO) are catalysts used in two component materials.

## Isocyanate Conditions



Spraying or dispensing fluids that contain isocyanates creates potentially harmful mists, vapors, and atomized particulates.

- Read and understand the fluid manufacturer's warnings and Safety Data Sheet (SDS) to know specific hazards and precautions related to isocyanates.
- Use of isocyanates involves potentially hazardous procedures. Do not spray with this equipment unless you are trained, qualified, and have read and understood the information in this manual and in the fluid manufacturer's application instructions and SDS.
- Use of incorrectly maintained or mis-adjusted equipment may result in improperly cured material, which could cause off gassing and offensive odors. Equipment must be carefully maintained and adjusted according to instructions in the manual.
- To prevent inhalation of isocyanate mists, vapors and atomized particulates, everyone in the work area must wear appropriate respiratory protection. Always wear a properly fitting respirator, which may include a supplied-air respirator. Ventilate the work area according to instructions in the fluid manufacturer's SDS.
- Avoid all skin contact with isocyanates. Everyone in the work area must wear chemically impermeable gloves, protective clothing and foot coverings as recommended by the fluid manufacturer and local regulatory authority. Follow all fluid manufacturer recommendations, including those regarding handling of contaminated clothing. After spraying, wash hands and face before eating or drinking.
- Hazard from exposure to isocyanates continues after spraying. Anyone without appropriate personal protective equipment must stay out of the work area during application and after application for the time period specified by the fluid manufacturer. Generally this time period is at least 24 hours.
- Warn others who may enter work area of hazard from exposure to isocyanates. Follow the recommendations of the fluid manufacturer and local regulatory authority. Posting a placard such as the following outside the work area is recommended:



## For all applications except spray foam



Spraying or dispensing fluids that contain isocyanates creates potentially harmful mists, vapors, and atomized particulates.

- Read and understand the fluid manufacturer's warnings and Safety Data Sheet (SDS) to know specific hazards and precautions related to isocyanates.
- Use of isocyanates involves potentially hazardous procedures. Do not spray with this equipment unless you are trained, qualified, and have read and understood the information in this manual and in the fluid manufacturer's application instructions and SDS.
- Use of incorrectly maintained or mis-adjusted equipment may result in improperly cured material. Equipment must be carefully maintained and adjusted according to instructions in the manual.
- To prevent inhalation of isocyanate mists, vapors, and atomized particulates, everyone in the work area must wear appropriate respiratory protection. Always wear a properly fitting respirator, which may include a supplied-air respirator. Ventilate the work area according to instructions in the fluid manufacturer's SDS.


Avoid all skin contact with isocyanates. Everyone in the work area must wear chemically impermeable gloves, protective clothing and foot coverings as recommended by the fluid manufacturer and local regulatory authority. Follow all fluid manufacturer recommendations, including those regarding handling of contaminated clothing. After spraying, wash hands and face before eating or drinking.

## Material Self-ignition



Some materials may become self-igniting if applied too thick. Read material manufacturer's warnings and Safety Data Sheet (SDS).

## Keep Components A and B Separate



Cross-contamination can result in cured material in fluid lines which could cause serious injury or damage equipment. To prevent cross-contamination:

- **Never** interchange component A and component B wetted parts.
- Never use solvent on one side if it has been contaminated from the other side.

## Moisture Sensitivity of Isocyanates

Exposure to moisture (such as humidity) will cause ISO to partially cure, forming small, hard, abrasive crystal that become suspended in the fluid. Eventually a film will form on the surface and the ISO will begin to gel, increasing in viscosity.

### NOTICE

Partially cured ISO will reduce performance and the life of all wetted parts.

- Always use a sealed container with a desiccant dryer in the vent, or a nitrogen atmosphere. **Never** store ISO in an open container.
- Keep the ISO pump wet cup or reservoir (if installed) filled with appropriate lubricant. The lubricant creates a barrier between the ISO and the atmosphere.
- Use only moisture-proof hoses compatible with ISO.
- Never use reclaimed solvents, which may contain moisture. Always keep solvent containers closed when not in use.
- Always lubricate threaded parts with an appropriate lubricant when reassembling.

**NOTE:** The amount of film formation and rate of crystallization varies depending on the blend of ISO, the humidity, and the temperature.

## Foam Resins with 245 fa Blowing Agents

Some foam blowing agents will froth at temperatures above 90°F (33°C) when not under pressure, especially if agitated. To reduce frothing, minimize preheating in a circulation system.

## Changing Materials

### NOTICE

Changing the material types used in your equipment requires special attention to avoid equipment damage and downtime.

- When changing materials, flush the equipment multiple times to ensure it is thoroughly clean.
- Always clean the fluid inlet strainers after flushing.
- Check with your material manufacturer for chemical compatibility.
- When changing between epoxies and urethanes or polyureas, disassemble and clean all fluid components and change hoses. Epoxies often have amines on the B (hardener) side. Polyureas often have amines on the B (resin) side.





# Systems

| Part   | Maximum Working Pressure, psi (MPa, bar) | Volts       | Proportioner Model | Unheated Hose 35 ft (10.6 m) | Cord Adapter   | Gun               |        |
|--------|--|-------------|--------------------|------------------------------|----------------|-------------------|--------|
|        |  |             |                    |                              |                | Model             | Part   |
| APT100 | 3000 (21, 207)                           | 100-120VAC  | 24T100             | 25R000                       | ---            | Fusion® Air Purge | 249810 |
| P2T100 | 3000 (21, 207)                           | 100-120VAC  | 24T100             | 25R000                       | ---            | PROBLER® P2       | GCP2RA |
| APT900 | 3000 (21, 207)                           | 200-240 VAC | 24R900             | 25R000                       | North America  | Fusion® Air Purge | 249810 |
| APT901 | 3000 (21, 207)                           | 200-240 VAC | 24R900             | 25R000                       | Europe         | Fusion® Air Purge | 249810 |
| APT902 | 3000 (21, 207)                           | 200-240 VAC | 24R900             | 25R000                       | Australia/Asia | Fusion® Air Purge | 249810 |
| P2T900 | 3000 (21, 207)                           | 200-240 VAC | 24R900             | 25R000                       | North America  | PROBLER® P2       | GCP2RA |
| P2T901 | 3000 (21, 207)                           | 200-240 VAC | 24R900             | 25R000                       | Europe         | PROBLER® P2       | GCP2RA |
| P2T902 | 3000 (21, 207)                           | 200-240 VAC | 24R900             | 25R000                       | Australia/Asia | PROBLER® P2       | GCP2RA |
| 24T900 | 3000 (21, 207)                           | 200-240 VAC | 24R900             | ---                          | North America  | ---               | ---    |
| 24T901 | 3000 (21, 207)                           | 200-240 VAC | 24R900             | ---                          | Europe         | ---               | ---    |
| 24T902 | 3000 (21, 207)                           | 200-240 VAC | 24R900             | ---                          | Australia/Asia | ---               | ---    |

## Models

The model no., series letter, and serial no. are located on the back of the cart. For faster assistance, please have that information ready before calling Customer Service.

| Bare Proportioner Part, Series | Volts       | * Electrical Connection                  | Maximum Working Pressure, psi (MPa, bar) | Approvals  |
|--------------------------------|-------------|--|--|--|
| 24T100, A                      | 100-120 VAC | 20 A cord (motor)<br>20 A cord (heaters) | 3000 (21, 207)                           |  <br><b>Intertek</b><br>9902471<br>Conforms to ANSI/UL Std. 499 Certified to CAN/CSA Std. C22.2 No. 88 |
| 24R900, A                      | 200-240 VAC | 15 A cord (motor)<br>15 A cord (heaters) | 3000 (21, 207)                           |  |

\* See page 16 for detailed electrical requirements.

# Related Manuals

The following manuals are for Reactor E-10hp components and accessories. Some are supplied with your package, depending on its configuration. Manuals are also available at [www.graco.com](http://www.graco.com).

| <b>Displacement Pump</b>            |                                    |
|-------------------------------------|------------------------------------|
| <b>Part No.</b>                     | <b>Description</b>                 |
| 311076                              | Instruction-Parts Manual (English) |
| <b>Fusion Air Purge Spray Gun</b>   |                                    |
| <b>Part No.</b>                     | <b>Description</b>                 |
| 309550                              | Instruction-Parts Manual (English) |
| <b>Probler P2 Spray Gun</b>         |                                    |
| <b>Part No.</b>                     | <b>Description</b>                 |
| 313213                              | Instruction-Parts Manual (English) |
| <b>Probler P2 Recirculation Kit</b> |                                    |
| <b>Part No.</b>                     | <b>Description</b>                 |
| 406842                              | Instruction-Parts Manual (English) |
| <b>Lift Ring Kit</b>                |                                    |
| <b>Part No.</b>                     | <b>Description</b>                 |
| 332977                              | Instruction-Parts Manual (English) |

# Overview

The Reactor E-10hp is a portable, electric-powered, 1:1 mix ratio proportioner for use with:

- Polyurea
- Polyurea hybrid coatings
- Polyurethane foam

Material may be applied with impingement mix spray guns.

The Reactor E-10hp is gravity-fed from 6 gal. (22.7 liter) supply tanks mounted on the unit.

Severe duty, positive displacement reciprocating piston pumps meter fluid flow to the gun for mixing and applying. When set to recirculation mode, Reactor E-10hp will circulate fluids back to the supply tanks.

The Reactor E-10hp uses primary heating rods and boost heating rods, for each fluid, and an insulated hose bundle with circulation return hoses. This allows the hoses and gun to be preheated to the desired temperature before spraying. The boost heating rods are used during circulation mode to reduce heatup time. Digital displays show the temperatures of the two fluids.

Electronic controls monitor fluid pressures, drive the motor, and alerts the operator if errors occur. See **Motor/Pump Status Codes**, page 15, for further information.

The Reactor E-10hp has two recirculation speeds, slow and fast, and an adjustable pressure output.

## Slow Recirculation



- Slow circulation results in a higher temperature transfer in the heater, so hoses and gun heat up quicker.
- Good for touchup or low flow spraying, up to moderate temperature.
- Not used to circulate full tanks up to temperature.
- Use with 245 fa blowing agent foams, to minimize heat returned to tank and reduce frothing.

## Fast Recirculation



- Use to support higher flow rates or higher temperatures by preheating the tanks.
- Agitates fluid within tanks, to avoid heating only the fluid at the top of the tank.
- Use for flushing.

## Pressure Adjust



Automatically maintains selected pressure output for dispensing or spraying.

# Component Identification

## Key for FIG. 1

- |   |   |   |  |
|---|---|---|--|
| A | Supply Tank (ISO)   | N | Desiccant Dryer  |
| B | Supply Tank (RES)   | P | Recirculation Tubes  |
| C | Pump (ISO)  | Q | Air Line Inlet (quick-disconnect fitting)                            |
| D | Pump (RES)  | R | Outlet Hose Connections  |
| E | Heater (under shroud)                                     | S | Return Hose Connections  |
| F | Fluid Pressure Gauges                                     | T | Fluid Temperature Sensors (located on heater assembly, under shroud) |
| G | Recirc/Spray and Overpressure Relief Valves               | U | Hose Rack and Control Shield   |
| H | Tank Level Sensors (bottom of tanks)                      | V | Fluid Inlet Ball Valves (each side)                                  |
| J | Control Panel; see FIG. 2, page 13                        | W | Fluid Inlet Strainers (each side)                                    |
| K | Electric Motor and Drive Housings                         | X | Power Cords (not shown)  |
| L | Insulated Hose Bundle (includes circulation return hoses) | Y | Fluid Temperature Gauges (each side)                                 |
| M | Fusion Air Purge Spray Gun                                | Z | Air Filter/Moisture Separator  |




FIG. 1: Component Identification

# Controls and Indicators

See **Controls and Indicators** identification table, page 14.

**NOTICE**

To prevent damage to soft key buttons, do not press the buttons with sharp objects such as pens, plastic cards, or fingernails.

## Heater Controls




FIG. 2. Heater Controls and Indicators

## System Controls








FIG. 3. System Controls and Indicators

## Controls and Indicators

| Key                      | Name                             | Description   |
|--------------------------|----------------------------------|---|
| <b>Heater Controls</b>   |                                  |   |
| AA                       | ISO Setpoint Increase            | Increases the temperature setpoint by one degree in the units selected within the setpoint limits. Press target key prior to adjusting.                               |
| AB                       | ISO Setpoint Decrease            | Decreases the temperature setpoint by one degree in the units selected within the setpoint limits. Press target key prior to adjusting.                               |
| AC                       | RES Setpoint Increase            | Increases the temperature setpoint by one degree in the units selected within the setpoint limits. Press target key prior to adjusting.                               |
| AD                       | RES Setpoint Decrease            | Decreases the temperature setpoint by one degree in the units selected within the setpoint limits. Press target key prior to adjusting.                               |
| AE                       | ISO Heater On/Off Key            | Turns heater on or off for ISO zone. Also clears heater zone diagnostic codes, see page 32.   |
| AF                       | RES Heater On/Off Key            | Turns heater on or off for RES zone. Also clears heater zone diagnostic codes, see page 32.   |
| AG                       | Actual Temperature Key           | Press to display actual temperature. Press and hold to display electrical current.  |
| AH                       | Target Temperature Key           | Press to display target temperature. Press and hold to display heater control circuit board temperature.  |
| AJ                       | Temperature Scale Key °F         | Press to change temperature scale to degrees Fahrenheit.  |
| AK                       | Temperature Scale Key °C         | Press to change temperature scale to degrees Celsius.   |
| AL                       | Temperature Display              | Show actual temperature or target temperature of heater zones, depending on selected mode. Defaults to actual at startup. Range is 32-170°F (0-77°C) for ISO and RES. |
| <b>Heater Indicators</b> |                                  |   |
| AM                       | ISO Heater Activity              | LEDs flash when heater zones are on. The duration of each flash shows the extent that the heater is turned on.  |
| AN                       | RES Heater Activity              | LEDs flash when heater zones are on. The duration of each flash shows the extent that the heater is turned on.  |
| AO                       | Actual Temperatures Active       | Actual temperatures are displayed.  |
| AP                       | Target Temperatures Active       | Target temperatures are displayed.  |
| AR                       | Fahrenheit Units Active          | Indicates that temperatures are displayed in °F.  |
| AS                       | Celsius Units Active             | Indicates that temperatures are displayed in °C.  |
| <b>System Controls</b>   |                                  |   |
| AT                       | Heater Power                     | Enables heater control. The switch includes a 20 A circuit breaker.   |
| AU                       | Motor Power                      | Enables motor. The switch includes a 20 A circuit breaker.  |
| AV                       | Motor Pump Control Function Knob | Selects operation mode / pressure setpoint. See <b>Motor/Pump Control Function Knob</b> , page 15.  |
| <b>System Indicators</b> |                                  |   |
| AW                       | Boost Heat Indicator             | Indicates boost heat is active.   |
| AX                       | Tank Level Indicator             | See <b>Tank Level Sensor LED</b> , page 15.   |
| AY                       | System Status Indicator          | Flashes an error code if alarm or deviation is active. See <b>Motor/Pump Status Codes</b> , page 15.  |

### Motor/Pump Control Function Knob

Use knob (AV) to select desired function.

| Icon  | Setting         | Function                                     |
|---|-----------------|--|
|  | Stop/Park       | Stops motor and automatically parks pumps.   |
|  | Slow Recirc     | Slow recirculation speed.                    |
|  | Fast Recirc     | Fast recirculation speed.                    |
|  | Pressure Adjust | Adjusts fluid pressure to gun in spray mode. |

### Motor/Pump Status Codes

If error occurs, status indicator (AY) will blink 1 to 19 times to indicate status code, pause, then repeat, or will blink other active error codes. See TABLE 1 for a brief description of status codes.

**Table 1: Motor/Pump Status Codes**

| No.   | Name  |
|-------|---|
| 1     | Pressure imbalance between ISO and RES sides  |
| 2     | Pressure deviation from setpoint              |
| 3     | Pressure transducer ISO failure               |
| 4     | Pressure transducer RES failure               |
| 5     | Excessive current draw                        |
| 6     | High motor temperature                        |
| 7     | No cycle counter switch input                 |
| 8     | High cycle rate deviation (more than 1.0 GPM) |
|       | High cycle rate shutdown (more than 1.1 GPM)  |
| 9     | Low tank level                                |
| 10    | Not used                                      |
| 11    | Locked motor rotor                            |
| 12    | Motor controller bus overvoltage              |
| 13    | Motor controller bus undervoltage             |
| 14    | Motor controller high temperature             |
| 15-19 | Motor controller fault                        |

**NOTE:** The default is to shut down if a status code indication occurs.

### Heater Control Diagnostic Codes

Heater control diagnostic codes appear on the temperature display. These alarms turn off heat.

**Table 2: Heater Control Diagnostic Codes**

| Code | Name  | Alarm Zone |
|------|---|------------|
| 01   | High fluid temperature                      | Individual |
| 02   | High zone current                           | Individual |
| 03   | No zone current with heater on              | Individual |
| 04   | Thermocouple not connected                  | Individual |
| 05   | High controller temperature                 | Individual |
| 06   | No communications with zone pod             | Individual |
| 09   | Display is missing                          | Individual |
| 99   | No communication with heater control module | Individual |

### Tank Level Sensor LED

The tank level sensor LED (AX) is triggered when chemical is not present in either tank.

**Table 3: Tank Level Indicator (AX)**

| Chemical   | Status   |
|------------|----------|
| > 1 gallon | Off      |
| < 1 gallon | Flashing |

# Setup

## Locate Reactor


1. Locate Reactor on a level surface.
2. Do not expose Reactor to rain.

|   |  |  |  |  |  |
|---|--|--|--|--|--|
|   |  |  |  |  |  |
| To avoid electric shock, always unplug both cords before servicing Reactor and wait one minute. |  |  |  |  |  |

## Electrical Requirements

|  |  |  |  |  |  |
|--|--|--|--|--|--|
|  |  |  |  |  |  |
| Improper wiring may cause electric shock or other serious injury if work is not performed properly. All electrical wiring must be done by a qualified electrician and comply with all local codes and regulations. |  |  |  |  |  |

1. Connect Reactor to the correct power source for your model. See *Table 4*. Power cords must be connected to two separate, dedicated circuits. See *FIG. 4*.
2. Some models include cord adapters for use outside North America. Connect the appropriate adapter to the unit's power cord before connecting to your power source.



**FIG. 4: Use Two Separate Circuits**

**Table 4: Electrical Requirements**

| Model  | Required Power Source  | Power Cord Connectors      | Supplied Local Adapters  |
|--|--|----------------------------|--|
| 200-240VAC, 1 phase, 50/60 Hz, two 15 ft (4.5 m) power cords | Two separate, dedicated circuits rated at minimum of 15 A each | <br>Two IEC 3-20 C20 Plugs | NEMA 6-15P (North America)<br>Euro CEE74 (Europe)<br>YP-39 AS3112 (Australia/Asia) |
| 100-120VAC, 50/60 Hz, two 15 ft (4.5 m) power cords          | Two separate dedicated circuits rated at minimum of 20 A each  | <br>Two NEMA 5-20P Plugs   |  |


**Table 5: Extension Cord Requirements**

| Model      | Required Wire Size |                     |
|------------|--------------------|---------------------|
|            | Up to 50 ft (15 m) | Up to 100 ft (30 m) |
| All models | AWG 12             | AWG 10              |

**NOTE:** Cords must be 3-conductor grounded, rated for your environment.



## Ground System



**Reactor:** grounded through power cord.

**Generator (if used):** follow your local code. Start and stop generator with power cord(s) disconnected.

**Spray gun:** grounded through the supplied fluid hoses, connected to a properly grounded Reactor. Do not operate without at least one grounded fluid hose.

**Object being sprayed:** follow your local code.

**Solvent pails used when flushing:** follow your local code. Use only metal pails, which are conductive, placed on a grounded surface. Do not place pail on a nonconductive surface, such as paper, plastic, or cardboard, which interrupts grounding continuity.

**To maintain grounding continuity when flushing or relieving pressure:** hold a metal part of spray gun firmly to the side of a grounded *metal* pail, then trigger gun.

## Connect Fluid Hoses

1. Connect fluid supply hoses to outlet hose connections (R, FIG. 5). Red hoses for ISO, blue for RES. Fittings are sized to prevent connection errors. Connect other end of hoses to ISO and RES inputs of gun.

**NOTE:** Probler guns use recirc accessory kit 24E727.

2. Connect recirculation hoses from gun recirculation ports to connections (S).




FIG. 5

## Connect Gun Air Hose

1. Connect gun air hose to the gun air input and to the air filter outlet (Z). If you are using more than one hose bundle, join the air hoses with the nipple provided with the hose bundle.
2. On units with Fusion guns, connect the supplied ball valve and quick-disconnect coupler to the gun air hose, then connect the coupler to the gun air fitting.

## Connect Main Air Supply

Connect the main air supply to the quick disconnect fitting (Q) on the unit. Air supply hose must be at least 5/16 in. (8 mm) ID up to 50 ft (15 m) or 3/8 in. (10 mm) ID up to 100 ft (30 m).





**NOTE:** Air Filter/Moisture Separator (Z) is equipped with an automatic moisture drain.

## Flush Before First Use


The Reactor is tested with a plasticizer oil at the factory. Flush out the oil with a compatible solvent before spraying. See **Flushing**, page 26.

## Fill Wet-Cups




Keep the felt washers in the pump wet-cups saturated with Graco ISO pump oil, Part No. 217374. The lubricant creates a barrier between the ISO and the atmosphere.

|   |   |   |  |  |  |  |
|---|---|---|--|--|--|--|
|    |  |  |  |  |  |  |
| <p>Pump rod and connecting rod move during operation. Moving parts can cause serious injury such as pinching or amputation. Keep hands and fingers away from wet-cup during operation. Shut off Motor Power  before filling wet-cup.</p> |   |   |  |  |  |  |

Fill wet-cups through slots in plate, or loosen screws and swing plate aside.



## Fill Fluid Tanks

|   |   |   |  |  |  |  |
|---|---|---|--|--|--|--|
|  |  |  |  |  |  |  |
|---|---|---|--|--|--|--|


### NOTICE


To prevent cross-contamination of fluids and equipment parts, **never** interchange (isocyanate) and (resin) parts or containers.


Have at least two 5 gal. (19 liter) pails to transfer fluid from drums to supply tanks. Label one pail "ISO" and the other "RES", using the red and blue labels provided. Always double-check which material you have before pouring it in the supply tanks. Pouring is easier if pails are not filled to the top.

Open only one supply tank at a time, to avoid splashing material from one tank into the other when filling.


**NOTE:** Using a drill and mixing blade, mix filled or separated materials in the pail before adding to the tanks. Material left in the tanks overnight may need to be remixed in the tanks.

1. Lift hose rack. Remove tank cover and pour ISO into tank (red side, with desiccant filter in cover).  
Replace cover .



 Add thin coating of grease lubricant to tank o-ring if lid is difficult to assemble to tank.

**NOTE:** Desiccant filter is blue when fresh, and turns pink when saturated. Be sure shipping plugs are removed from openings on desiccant filter.

2. Remove tank cover and pour resin into RES tank (blue side). Replace cover .


## Purge Air and Flush Fluid From Lines





To avoid fire and explosion:

- Flush equipment only in a well-ventilated area.
- Ensure main power is off and heater is cool before flushing.
- Do not turn on heater until fluid lines are clear of solvent.


1. Remove both recirculation tubes (P) from the tanks and secure each one in a dedicated waste container.




2. Set function knob to Stop/Park .




3. Plug in power cord(s). See Table 2, page 16.
4. Open both pump fluid inlet valves (V, shown in open position).




5. Turn on Motor Power. System status indicator (AY) should turn on.





6. Set Recirc/Spray valves to Recirc.



7. Set function knob to Slow Recirc  or Fast Recirc .



8. When clean fluids exit both recirculation tubes (P), set function knob to Stop/Park .



9. Replace recirculation tubes in supply tanks.


# Startup

|  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|


Heated fluid can cause equipment surfaces to become very hot. To avoid severe burns:

- Do not operate Reactor without all covers and shrouds in place.
- Do not touch hot fluid or equipment.
- Allow equipment to cool completely before touching it.

1. Perform **Setup**, page 16.
2. Set function knob to Slow Recirc or Fast Recirc . See **Heatup Guidelines**, page 21, then continue with steps 3-6.



3. Turn on Heater Power.



4. Set temperatures:
  - a. Press or to change temperature scale.
  - b. Press to display target temperatures.
  - c. To set **ISO** heat zone target temperature, press or until display shows desired temperature. Repeat for **RES** zone.

- d. Press to display actual temperatures.

5. Circulate through heater until temperature readouts display desired temperature. See Table 6.
6. Adjust heat controls as necessary for a stable spray temperature.

**Table 6: Approximate heatup time for starting a cold machine with 5 gallons (19 liters) per side**

| Fluid Spray Target Temperature | 120VAC     | 230VAC                         |
|--------------------------------|------------|--------------------------------|
|                                |            | 35 ft (10.7 m) Hose (1 bundle) |
| 125°F (52°C)                   | 15 minutes | 10 minutes                     |
| 170°F (77°C)                   | 40 minutes | 20 minutes                     |

**NOTE:** Heatup times are based on 70°F (21°C) starting material temperature and 70°F (21°C) ambient temperature.

**NOTE:** Different fluids will absorb heat at different rates. When refilling a warm machine, heatup times will be less.

## Heatup Guidelines

The fluids must be circulated from the pumps through the heater, hoses, and back to the tanks to ensure warm fluids are supplied to the gun.

### Slow Recirculation


- Slow Recirc results in a higher temperature transfer in the heater, so hoses and gun heat up quicker.
- Good for touchup or low flow spraying, up to moderate temperature.

### Fast Recirculation

Fast Recirc keeps heaters on full-time to bring fluid tanks up to temperature. The higher your flow rate, the more heat needed in the tanks before spraying.

- *For 200-240VAC systems:* Use Fast Recirc until pump inlet fluid temperature gauges (Y) are within 45°F (25°C) of target outlet temperature.
- *For 100-120VAC systems:* Use Fast Recirc until pump inlet fluid temperature gauges (Y) are within 30°F (17°C) of target temperature.
- *Volume in tanks:* Use only what you need. For example, 2.5 gal. (10 l) in each tank will heat up almost twice as fast as 5 gal. (20 l).
- Mixes fluid within tanks, to avoid heating only the fluid at the top of the tank.
- Use for flushing.


## Heat Management Tips


- Heaters perform better with lower flow rates or smaller mix modules.
- Triggering the gun for short periods helps maintain efficient heat transfer, keeping material at the desired temperature. Triggering the gun for a long period may not allow enough heating time, depending on material temperature in tanks.
- If temperature displays fall below acceptable limits, set function knob to Slow Recirculation  and circulate again to bring temperatures back up.
- Each 35 ft (10.7 m) hose bundle adds about 5 minutes to heatup time, with most materials. Maximum recommended hose length is 105 ft (32 m).
- For a quicker start, do initial heatup circulation with the tanks 1/4 to 1/3 filled, then add more material.


# Spraying




**NOTE:** Air is supplied to spray gun with gun piston safety lock or trigger safety lock engaged and gun fluid manifold valves closed (if present).





1. Set function knob to Stop/Park . Verify system status indicator LED is on.




2. Set Recirc/Spray valves to Spray.



3. Turn function knob to Pressure Adjust . Keep turning to the right until fluid pressure gauges show desired pressure.




4. Check fluid pressure gauges to ensure proper pressure balance. If imbalanced, reduce pressure of higher component by **slightly** turning Recirc/Spray valve for that component toward Recirc, until gauges show balanced pressures. The pressure imbalance alarm (Status Code 1) is inactive for 10 seconds after entering spray pressure mode, to allow time to balance pressures.



*In this example, RES side pressure is higher, so use the RES side valve to balance pressures.*


**NOTE:** Watch gauges for 10 seconds to be sure pressure holds on both sides and pumps are not moving.

5. Open gun fluid manifold valves (impingement mix guns only).



**NOTE:** On impingement guns, never open fluid manifold valves or trigger gun if pressure are imbalanced.

6. Disengage piston safety lock or trigger safety lock.



7. Test spray onto cardboard or plastic sheet. Verify that material fully cures in the required length of time, and is the correct color. Adjust pressure and temperature to get desired results. Equipment is ready to spray.

# Pause


To bring the hose and gun back to spray temperature after a brief break, use the following procedure.


1. Engage piston safety lock or trigger safety lock.




Fusion

Probler

2. Set function knob to Slow Recirc .



3. Set Recirc/Spray valves to Recirc until temperature readouts come back up.



4. *If you stop spraying for more than 2 minutes when using an impingement mix gun, close gun fluid valves. Doing this will keep the internal parts of the gun cleaner and prevent crossover.*



Fusion



Probler

# Refill Tanks

Material can be added to the tanks at any time. See **Fill Fluid Tanks**, page 18.

**NOTE:** If you are operating at high temperatures or flow rates, follow **Pause** instructions to bring tanks up to temperature.

| NOTICE  |
|---|
| <p>To prevent cross-contamination of fluids and equipment parts, <b>never</b> interchange ISO and RES parts or containers.</p> <p>Have at least two 5 gal. (19 liter) pails to transfer fluid from drums to supply tanks. Label one pail "ISO" and the other "RES", using the red and blue labels provided. Always double-check which material you have before pouring it in the supply tanks. Pouring is easier if pails are not filled to the top.</p> <p>Open only one supply tank at a time, to avoid splashing material from one tank into the other when filling.</p> |

# Pressure Relief Procedure




Follow the Pressure Relief Procedure whenever you see this symbol.




This equipment stays pressurized until pressure is manually relieved. To help prevent serious injury from pressurized fluid, such as skin injection, splashing fluid and moving parts, follow the Pressure Relief Procedure when you stop spraying and before cleaning, checking, or servicing the equipment.


1. Engage piston safety lock or trigger safety lock.



**Fusion**


**Probler**

2. Set function knob to Stop/Park .



ti21490a

3. Turn Recirc/Spray valves to Recirc. Fluid will be dumped to supply tanks. Pumps will move to the bottom of their stroke. Ensure gauges drop to 0.



ti21495a

# Shutdown

**NOTE:** For longer breaks (more than 10 minutes) use the following procedure. If you will be shutdown for more than 3 days, first see **Flushing**, page 26.

1. Shut off Heater Power.



2. Shut off Motor Power.




3. Follow all steps of **Pressure Relief Procedure**, page 24.

4. Close gun fluid valves ISO and RES. Doing this will keep the internal parts of the gun cleaner and prevent crossover.



**Fusion**




**Probler**

5. Refer to your separate gun manual and perform **Shutdown** procedure.



# Maintenance

- Check pump wet-cups fluid level daily, page 18.
- Throat u-cup is not adjustable. Do not overtighten packing nut/wet-cup.
- Keep component ISO from exposure to moisture in atmosphere, to prevent crystallization.
- Wipe supply tank lid o-ring, inner rim, and inner tank walls daily to prevent ISO crystallization. Keep film of grease on o-ring and inside of lid.
- Check desiccant filter weekly. Filter is blue when fresh, and turns pink when saturated.
- Remove plug (X) and clean fluid inlet strainer (S) as needed. Always clean the fluid inlet strainers after flushing.



- Generally, flush if you will shutdown for more than three days. Flush more often if material is moisture sensitive and humidity is high in the storage area, or if material may separate or settle out over time.
- *If using an impingement mix gun, close gun fluid valves when not spraying. Doing this will keep the internal parts of the gun cleaner and prevent cross-over. Clean gun mix chamber ports and check valve screens regularly. See gun manual.*



## Fusion



## Probler

- *If using an Fusion Air Purge impingement mix gun, always grease the gun after use until purge air carries grease mist out the front of the gun. Use Part No. 117773 Grease. See gun manual.*


# Flushing

|  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|


To avoid fire and explosion:

- Flush equipment only in a well-ventilated area.
- Ensure main power is off and heater is cool before flushing.
- Do not turn on heater until fluid lines are clear of solvent.

- Generally, flush if you will be shut down for more than 3 days. Flush more often if material is moisture sensitive and humidity is high in the storage area, or if material may separate or settle out over time.
  - Flush out old fluid with new fluid, or flush out old fluid with a compatible solvent before introducing new fluid.
  - Use the lowest possible pressure when flushing.
  - Always leave some type of fluid in system. Do not use water.
  - For long term storage, flush out the solvent with a storage fluid such as Bayer Mesamoll plasticizer or, at minimum, clean motor oil.
1. Engage piston safety lock or trigger safety lock. Close fluid valves ISO and RES. Leave air on.




2. Set function knob to Stop/Park




3. Shut off Heater Power. Allow system to cool.




4. Remove recirculation tubes (P) from supply tanks and place in original containers or waste containers.




5. Turn Recirc/Spray valves to Recirc.




6. Set function knob to Fast Recirc . Pump material from supply tanks until no more comes out.





7. Set function knob to Stop/Park





8. Wipe out any remaining material from the supply tanks. Fill each supply tank with 1-2 gal. (3.8-7.6 l) of solvent recommended by your material manufacturer.


9. Set function knob to Fast Recirc . Pump solvent through system to waste containers.



10. When nearly clear solvent comes from recirculation tubes, set function knob to Stop/Park . Return recirculation tubes to supply tanks.



11. Set function knob to Fast Recirc . Circulate solvent through system for 10-20 minutes to ensure thorough cleaning.






**NOTE:** To flush gun, refer to gun instruction manual.


## Purge Hoses

Disconnect hoses from gun and secure back into the tanks for thorough cleaning with solvent.

- Turn Recirc/Spray valve ISO to Spray.



- Open gun into waste ISO container.
- Set function knob to Slow Recirc  until hose is flushed.
- Set function knob to Stop/Park .
- Repeat for RES side.

12. Set function knob to Stop/Park .

13. Solvent flushing is a two step process. Go back to step 4, drain solvent, and flush again with fresh solvent.

14. Leave unit filled with solvent, plasticizer, clean motor oil, or refill supply tanks with new material and re-prime.

**NOTE:** Never leave the unit dry unless it has been disassembled and cleaned. If fluid residue dries in the pumps, the ball checks may stick the next time you use the unit.

# Troubleshooting

## Pump Control Status Codes

Determine the status code by counting the number of times the system status indicator blinks. The status indicator will blink 1-19 times to indicate a status code.

Multiple active status codes are separated by a longer duration pause.


### Status Code 1: Pressure Imbalance

**NOTE:** The unit does not check for pressure imbalance at setpoints less than 300 psi (2.1 MPa, 21 bar).

**NOTE:** The unit does not check for pressure imbalance for 10 sec after entering pressure mode.

Unit senses pressure imbalance between components ISO and RES, and warns or shuts down, depending on settings of DIP switches 1 and 2. To turn off automatic shutdown and/or tighten pressure tolerances for status code 1, see **DIP Switch Settings**, page 30.

1. Reduce pressure of higher component by **slightly** turning Recirc/Spray valve for that component toward Recirc, until gauges show balanced pressures.



*In this example, RES side pressure is higher, so use the RES side valve to balance pressures.*

2. If pressure imbalance continues, see **Proportioner Troubleshooting**, page 37.

### Status Code 2: Pressure Deviation from Setpoint

**NOTE:** The unit does not check for pressure deviation at setpoint less than 400 psi (2.8 MPa, 28 bar).

Unit senses pressure deviation from setpoint, and warns or shuts down, depending on settings of DIP switches 3 and 4. If equipment cannot maintain enough pressure for a good mix with an impingement mix gun, try using a smaller mix chamber or nozzle.

To turn off automatic shutdown and/or change pressure tolerances for status code 2, see **DIP Switch Settings**, page 30.

Deviation can occur if power is turned on if function knob (AV) is not set to Park/Off. Leave knob in Park/Off mode until status indicator LED turns on.

### Status Code 3: Pressure Transducer ISO Failure

1. Check transducer ISO electrical connection (J11) at board, page 46.
2. Reverse ISO and RES transducer electrical connections at board, page 46. If error moves to transducer RES (Status Code 4), replace transducer ISO, page 51.

### Status Code 4: Pressure Transducer RES Failure

1. Check transducer RES electrical connection (J12) at board, page 46.
2. Reverse ISO and RES transducer electrical connections at board, page 46. If error moves to transducer ISO (Status Code 3), replace transducer RES, page 51.

### Status Code 5: Excessive Current Draw

1. Shut off unit and retry operation. Brushes may not be fully seated.
2. Check fan operation. Elevated temperature can cause excessive current draw.
3. Locked rotor; motor unable to turn. Replace motor, page 54.
4. Short on control board. Replace board, page 45.
5. Worn or hung up motor brush causing arcing of brush at commutator. Replace brushes, page 55.
6. Disconnect motor connections from the control board. Cycle power.
  - a. If status code 5 is still present, replace the board.
  - b. If status code 5 is not active, test motor. See **Test Motor**, page 54.

### Status Code 6: High Motor Temperature

Motor is running too hot.

1. Reduce pressure duty cycle, gun tip size, or move Reactor to a cooler location. Allow 1 hour for cooling.
2. Check fan operation. Clean fan and motor housing.
3. Check J9 overtemperature connector on control board.

### Status Code 7: No Cycle Counter Switch Input

Have not received input from cycle counter switch for 10 seconds after selecting Recirc mode or unit is unable to park within 15 seconds of entering park mode.

1. Verify that recirc valves are open and unit is set to Recirc mode.
2. Check cycle counter switch connection to board (J10), see FIG. 12, page 46.
3. Check that magnet (224) and cycle counter switch (223) are in place under RES side motor end cover (229). Replace if necessary.

### Status Code 8: High Cycle Rate

System is spraying more than 1 gpm. System will shut-down if spraying more than 1.1 gpm.

1. Reduce pressure and/or gun tip size.

### Status Code 9: Low Tank Level

The tank level sensors sense ISO and RES material density inside the tank, and warns or shuts down, depending on settings of DIP switch 5. See **DIP Switch Settings**, page 30.

1. Add material to supply tank, if necessary.
2. Check that the tank level sensor is in contact with the surface of the tank. Replace if necessary. See **Tank Fluid Level Sensors**, page 56.

3. Check J6 connections on control board. See Table 8, page 46.

| Level Sensor LED | Status                          |
|------------------|---------------------------------|
| Green - on       | Sensor is powered               |
| Green - off      | Sensor is not powered           |
| Yellow - on      | Sensor detects material         |
| Yellow - off     | Sensor does not detect material |

### Status Code 11: Locked Motor Rotor

Verify that pumps are not seized and move freely. The motor is unable to turn. Replace motor, page 54.

Shut off unit and contact distributor before resuming operation.

### Status Code 12: Motor Controller Overvoltage

Too much voltage connected to control board. See **Technical Data**, page 76, for power requirements.

Cycle power and check status indicator to see if error is still active.

### Status Code 13: Motor Controller Undervoltage

Not enough voltage connected to control board. See **Technical Data**, page 76, for power requirements.

Cycle power and check status indicator to see if error is still active.

### Status Code 14: Motor Controller High Temperature



The motor control board is too hot.

Shutdown and move Reactor to a cooler location. Allow 1 hour for cooling.


### Status Code 15-19: Motor Controller Faults

Cycle power. If error is still present, replace board. See, page 45.

## DIP Switch Settings

|   |   |  |  |  |  |  |
|---|---|--|--|--|--|--|
|                      |  |  |  |  |  |  |
| To avoid electric shock, always unplug both power cords before servicing Reactor and wait one minute. |   |  |  |  |  |  |

1. Turn power off and unplug power cords from wall outlets.
2. Remove screws and display cover (26).



ti21923a

3. Locate the DIP switch on the control board.



**FIG. 6: DIP Switch**

4. Set DIP switches to the desired positions. See **DIP Switch Settings and Functions**, page 31
5. Replace display cover (26) and plug in unit.
6. Cycle power switch to activate changes to DIP switch.

## DIP Switch Settings and Functions

| DIP Switch Settings and Functions  |   |  |
|--|---|--|
| DIP Switch and Function  | OFF   | ON   |
| <b>DIP Switch 1</b><br>If selected, displays a status code or displays a status code and causes shutdown if the pressure imbalance exceeds selection made in DIP Switch 2. | DEVIATION   | DEVIATION AND SHUTDOWN   |
| <b>DIP Switch 2</b><br>Select pressure imbalance limits, that if exceeded, will cause a deviation and a shutdown (if enabled).   | See <b>Dip Switch 1 and 2 Settings</b> table, page 31                 |  |
| <b>DIP Switch 3</b><br>If selected, causes shutdown or displays a status code due to deviation of pressure from setpoint exceeds selection made in DIP Switch 4.           | DEVIATION   | *SHUTDOWN  |
| <b>DIP Switch 4</b><br>Causes deviation if pressure setpoint is greater than:  | 300 psi (2.1 MPa, 21 bar)<br><br>(25% if < 800 psi [5.6 MPa, 56 bar]) | *500 psi (3.5 MPa, 35 bar)<br><br>(40% if < 800 psi [5.6 MPa, 56 bar]) |
| <b>DIP Switch 5</b><br>Causes shutdown or displays a status code for low fluid level in tanks.   | *DEVIATION  | SHUTDOWN   |
| <b>DIP Switch 6</b><br>Enables or disables boost heat.   | DISABLE   | *ENABLE  |
| <b>DIP Switch 7</b>  | Not used  |  |
| <b>DIP Switch 8</b>  | Not used  |  |


\* Default DIP Switch Settings

| DIP Switch 1 and 2 Settings |              |                           |                           |
|-----------------------------|--------------|---------------------------|---------------------------|
| DIP Switch 1                | DIP Switch 2 | Deviation                 | Shutdown                  |
| Off                         | Off          | 300 psi (2.1 MPa, 21 bar) | ---                       |
| Off                         | *On          | 500 psi (3.5 MPa, 35 bar) | ---                       |
| *On                         | Off          | 300 psi (2.1 MPa, 21 bar) | 500 psi (3.5 MPa, 35 bar) |
| *On                         | *On          | 500 psi (3.5 MPa, 35 bar) | 800 psi (5.6 MPa, 56 bar) |

## Heat Control Diagnostic Codes

Heat control diagnostic codes appear on the temperature display.

These alarms turn off heat. Codes E03 and E04 can be

cleared by pressing  .

1. To clear other codes:
2. Shut off Heater Power.



3. Shut off Motor Power.



4. Turn on Motor Power and Heater power to clear.



| Code | Code Name                  | Alarm Zone | Corrective Action page |
|------|----------------------------|------------|------------------------|
| 01   | High fluid temperature     | Individual | 32                     |
| 02   | High zone current          | Individual | 33                     |
| 03   | No zone current            | Individual | 33                     |
| 04   | Thermocouple not connected | Individual | 33                     |

### E01: High Fluid Temperature

- Thermocouple ISO or RES (310) senses a fluid temperature above 260°F (71°C).
- Overtemperature switch ISO or RES (308) senses a fluid temperature above 230°F (110°C) and opens. At 190°F (87°C) the switch closes again.
- Thermocouple ISO or RES (310) fails, is damaged, is not touching the heater element (307), or has a poor connection to the temperature control board.
- Overtemperature switch (308) fails in the open position.
- The temperature control board fails to turn off any heat zone.
- Zone power wires or thermocouples are switched from one zone to another.

- Failed heater element where thermocouple is installed.
- Loose wire

### E01 Checks

|   |   |  |  |  |  |  |
|---|---|--|--|--|--|--|
|  |  |  |  |  |  |  |
|---|---|--|--|--|--|--|

Troubleshooting this equipment requires access to parts that may cause electric shock or other serious injury if work is not performed properly. Have a qualified electrician perform all electrical troubleshooting. Be sure to shut off all power to the equipment before repairing.

**NOTE:** Before checking the thermocouple, note which zone (ISO or RES) has high fluid temperature.

1. Check that connector B is firmly plugged into heater control module. See **Temperature Control Modules Connections**, page 48.
2. Clean and re-plug connections.
3. Check connections between the temperature control module and overtemperature switch, and between the temperature control module and thermocouples. Ensure all wires are securely connected to connector B on heater control module. See Table 7, page 33.



4. Remove connector B from heater control module and check continuity of thermocouples by measuring resistance across pins on the plug end.
5. Verify fluid temperature, using an external temperature sensing device.

**Table 7: Connector B Resistance Measurements**

| 120V      |      | 230V      |          | Description                  | Reading       |
|-----------|------|-----------|----------|------------------------------|---------------|
| Connector | Pin  | Connector | Pin      |                              |               |
| B1        | 1, 2 | B1        | 1, 2     | Overtemperature Switch       | nearly 0 ohms |
| B2        | 1    | B1        | 5        | Thermocouple ISO, R (red)    | 4-6 ohms      |
| B2        | 2    | B1        | 6        | Thermocouple ISO, Y (yellow) |               |
| B2        | 4    | B1        | 8        | Thermocouple RES, R (red)    | 4-6 ohms      |
| B2        | 5    | B1        | 9        | Thermocouple RES, Y (yellow) |               |
| B2        | 3    | B1        | 3-4,7,10 | Unused                       | N/A           |

**If temperature is too high (sensor reading is 260°F [127°C] or above):**

6. Check if thermocouples are damaged, or not contacting the heater element, see FIG. 16, page 50.
7. Check if temperature control module turns off when equipment reaches temperature setpoint:
  - a. Set temperature setpoints far below displayed temperature.
  - b. Turn zone on. If temperature rises steadily, power board is failing.
  - c. Verify by exchanging with another power module. See **Replace Temperature Control Modules**, page 47.
  - d. If the exchanged module does not fix the problem, the power module is not the cause.
8. Verify continuity of heater elements with an ohmmeter, see page 49.

**E02: High zone current**

When there is a high current error, the LED on that zone's module will turn red while the error is displayed.

1. See **Before Beginning Repair**, page 40.
2. Exchange zone module with another one. Turn zone on and check for error. If error disappears, replace faulty module.

**E03: No zone current**

When a no current error occurs, the LED on the specific zone's module turns red when the error is displayed.

1. Check for tripped circuit breaker on Reactor or at power source of that zone. Replace circuit breaker if it trips habitually.
2. Check for loose or broken connection at that zone.
3. Exchange zone module with another one. Turn zone on and check for error (see page 47). If error disappears, replace faulty module.
4. If E03 occurs for all zones, the contactor may not be closing. Verify wiring from heater control to contactor coil.

**E04: Thermocouple disconnected**

1. Check temperature sensor connections to green connectors (B) on temperature control module. See **Temperature Control Modules Connections**, page 48.
2. Unplug and re-plug sensor wires.

## Reactor Electronics



Before performing any troubleshooting procedures:



1. Shut off Heater Power.



2. Shut off Motor Power.



3. Relieve pressure, page 24.
4. Allow equipment to cool.
5. Try the recommended solutions in the order given for each problem, to avoid unnecessary repairs. Also, determine that all circuit breakers, switches, and controls are properly set and wiring is correct before assuming there is a problem.

| PROBLEM                                    | CAUSE   | SOLUTION   |
|--|---|--|
| Temperature display does not illuminate.   | Display disconnected.   | Check cable connections, page 46.  |
|  | Display cable damaged or corroded.                            | Clean connections; replace cable if is damaged.  |
|  | Blown fuse.   | Replace fuse (73) in fuse holder on DIN rail assembly located under electronics cover (55).  |
|  | Failed circuit board.   | Display is failing. Replace.   |
|  | Loose display cables on control board.                        | Check cable connections to each display, FIG. 23 on page 73.   |
|  | Failed control board (displays get power from control board). | Remove access panel. Check if board LED is lighted. If not, replace board, page 45.  |
|  | Inadequate power to control board.                            | Check that power supply meets requirements.  |
|  | Loose power cable.  | Check cable connections, FIG. 23 on page 73.   |
| Erratic display; display turns on and off. | Heater power switch circuit breaker tripped.                  | Display is powered from heater power circuit breaker. Cycle heater power off  , then on  to reset breaker. |
|  | Low voltage.  | Ensure input voltage is within specifications, page <b>Technical Data</b> , page 76.   |
|  | Poor display connection.                                      | Check cable connections, FIG. 23 on page 73. Replace damaged cable.  |
|  | Display cable damaged or corroded.                            | Clean connections; replace cable if is damaged.  |

| PROBLEM   | CAUSE   | SOLUTION  |
|---|---|---|
| Display does not respond properly to button pushes. | Poor display connection.                                      | Check cable connections, FIG. 23 on page 73. Replace damaged cable. |
|   | Display cable damaged or corroded.                            | Clean connections, FIG. 23 on page 73. Replace damaged cable.       |
|   | Ribbon cable on display circuit board disconnected or broken. | Connect cable, FIG. 23 on page 73, or replace.                      |
|   | Broken display button.  | Replace, page 43.   |
| Fan not working.                                    | Loose wire.   | Check fan wire.   |
|   | Defective fan.  | Replace, page 55.   |

## Heaters



Before performing any troubleshooting procedures:

1. Shut off Heater Power.




2. Shut off Motor Power.



3. Relieve pressure, page 24.
4. Allow equipment to cool.

Try the recommended solutions in the order given for each problem, to avoid unnecessary repairs. Also, determine that all circuit breakers, switches, and controls are properly set and wiring is correct before assuming there is a problem.

| PROBLEM  | CAUSE                                       | SOLUTION  |
|--|---|---|
| Primary heater(s) does not heat.   | Heat turned off.                            | Press <b>ISO</b> or <b>RES</b> zone  keys.   |
|  | Temperature control alarm.                  | Check temperature display for diagnostic code, page 32.   |
|  | Signal failure from thermocouple.           | See <b>E04: Thermocouple disconnected</b> , page 33.  |
|  | Failed heater element.                      | Check resistance of heater elements. See <b>Test Heater Element</b> , page 49.  |
| Control of primary heat is abnormal; high temperature overshoots or E01 error occurs intermittently. | Dirty thermocouple connections.             | Examine connection of thermocouples to long green plug on heater control board. Unplug and re-plug thermocouple wires, cleaning off any debris. For 100-120VAC, unplug and re-plug long green connector. For 200-240V, unplug and re-plug green connector(s) B. |
|  | Thermocouple not contacting heater element. | Loosen ferrule nut (N), push in thermocouple (310) so tip (T) contacts heater element (307). Holding thermocouple tip (T) against heater element, tighten ferrule nut (N) 1/4 turn past tight. See page 50 for illustration.                                    |
|  | Failed heater element.                      | See <b>Heaters</b> , page 36.   |
|  | Signal failure from thermocouple.           | See <b>E04: Thermocouple disconnected</b> , page 33.  |
|  | Thermocouple wired incorrectly.             | See <b>E04: Thermocouple disconnected</b> , page 33. Power up zones one at a time and verify that temperature for each zone rises.  |

# Proportioner



Before performing any troubleshooting procedures:

1. Shut off Heater Power.






2. Shut off Motor Power.



3. Relieve pressure, page 24.
4. Allow equipment to cool.

Try the recommended solutions in the order given for each problem, to avoid unnecessary repairs. Also, determine that all circuit breakers, switches, and controls are properly set and wiring is correct before assuming there is a problem.

| PROBLEM                   | CAUSE  | SOLUTION   |
|---------------------------|--|--|
| Reactor does not operate. | No power.  | Plug in both power cords.  |
|                           |  | Cycle Motor Power and Heater Power off  , then on  to reset both breakers. |
| Motor does not operate.   | Power turned on while function knob set to a run position.             | Set function knob to Stop/Park  , once status LED turns on. Then select desired function.  |
|                           | Loose connection on control board.                                     | Check connection at motor power connections on bottom board. See FIG. 12, page 46.   |
|                           | Worn brushes.  | Check both sides. Replace brushes worn to less than 1/2 in. (13 mm), see page 55.  |
|                           | Broken or misaligned brush springs.                                    | Realign or replace, page 55.   |
|                           | Brushes or springs binding in brush holder.                            | Clean brush holder and align brush leads for free movement.  |
|                           | Shorted armature.  | Replace motor, page 54.  |
|                           | Check motor commutator for burn spots, black pitting, or other damage. | Remove motor. Have motor shop resurface commutator, or replace motor, page 54.   |
|                           | Failed control board.  | Replace board. See page 45.  |
| Pump output low.          | Plugged fluid inlet strainer.  | Clear, see page 25.  |
|                           | Leaking or plugged piston valve or intake valve in displacement pump.  | Check valves. See pump manual.   |

| PROBLEM   | CAUSE   | SOLUTION   |
|---|---|--|
| One side doesn't come up to pressure in spray mode.   | Low fluid in tank.  | Refill.  |
|   | Dirty or damaged Recirc/Spray valve.  | Clean or repair, page 41.  |
|   | Plugged fluid inlet strainer.   | Clear, see page 25.  |
|   | Pump intake valve plugged or stuck open.  | Clean pump intake valve. See page 42.  |
|   | Material is too viscous to pump.  | Warm material before adding to tanks.  |
| Pressure is higher on one side when setting pressure with function knob.                        | Pump intake valve partially plugged.  | Clean pump intake valve. See page 42.  |
|   | Air in hose. Fluid is compressible.   | Purge air from hose.   |
|   | Unequal size hoses or unequal hose construction.  | Use matching hoses, or balance pressures before spraying.                                |
| Pressures are not balanced when running, but pressure is generated and holds on both strokes.   | Unequal viscosities.  | Change temperature setting to balance viscosities.                                       |
|   |   | Change restrictor at mix point to balance back pressure.                                 |
|   | Restriction on one side.  | Clean mix module or restrictor at mix manifold.  |
|   |   | Clean gun check valve screens.   |
| Fluid leak in pump packing nut area.  | Worn throat seals.  | Replace. See pump manual.  |
| Pressure doesn't hold when stalled against gun in spray mode.                                   | Leaking Recirc/Spray valve.   | Repair, page 41.   |
|   | Leaking piston valve or intake valve in displacement pump.  | Repair. See pump manual.   |
|   | Leaking gun shutoff.  | Repair. See gun manual.  |
| Pressure is higher on RES side during startup of recirculation, especially in High Recirc mode. | This is normal. RES is typically higher viscosity than ISO until the material is heated during recirculation. | No action required.  |
| One gauge shows half as many pulses as the other when pumps are cycling.                        | Loss of pressure on downstroke.   | Intake valve is leaking or not closing. Clean or replace valve; see page 41.             |
|   | Loss of pressure on upstroke.   | Piston valve is leaking or not closing. Clean or replace valve or packings; see page 41. |
| Status indicator not lit.   | Function knob is not set to Park/Off when power is applied.   | Turn function knob to Park/Off.  |
|   | Loose indicator cable.  | Check that cable is connected at J3 on top motor control board. See page 46.             |
|   | Failed control board.   | Replace board. See page 45.  |
|   | Shorted pressure transducer or potentiometer input.   | See <b>Control Board LEDs</b> , page 45 for troubleshooting.                             |

| PROBLEM  | CAUSE  | SOLUTION  |
|--|--|---|
| ISO side rich; lack of RES side.   | ISO side gauge is low.                       | RES side restriction downstream of gauge. Check gun check valve screen, mix module, or mix manifold restrictor. |
|  | RES side gauge is low.                       | RES side material supply problem. Check RES side inlet strainer and pump intake valve.                          |
| RES side rich; lack of ISO side.   | ISO side gauge is low.                       | ISO side material supply problem. Check ISO side inlet strainer and pump intake valve.                          |
|  | RES side gauge is low.                       | ISO side restriction downstream of gauge. Check gun check valve screen, mix module, or mix manifold restrictor. |
| Tank level sensor does not sense empty tank (indicator LED on control panel never blinks).   | Material build up.                           | Flush and clean inside of tanks. Clean outside of sensor and recessed area on tank.                             |
|  | LED wires disconnected inside control panel. | Reconnect LED wires.  |
|  | Tank level sensor sensitivity is too high.   | Reset tank fluid level sensor sensitivity, page 57.   |
| Tank level sensor does not sense full tank (indicator LED on control panel always blinking). | Tank level sensor is too far away from tank. | Check position of both tank level sensors. See <b>Tank Fluid Level Sensors</b> , page 56.                       |
|  | Sensor wires disconnected.                   | Reconnect sensor wires in display panel.  |
|  | Tank level sensor sensitivity is too low.    | Reset tank fluid level sensor sensitivity, page 57.   |


# Repair

## Before Beginning Repair

|  |  |  |  |  |  |
|--|--|--|--|--|--|
|  |  |  |  |  |  |
| <p>Repairing this equipment requires access to parts which may cause electric shock or other serious injury if work is not performed properly. Have a qualified electrician connect power and ground to main power switch terminals, see page 16. Be sure to shut off all power to the equipment before repairing.</p> |  |  |  |  |  |

1. Flush if possible, see page 26. If not possible, clean all parts with solvent immediately after removal, to prevent isocyanate from crystallizing due to moisture in the atmosphere.

2. Set function knob to Stop/Park



3. Shut off Motor Power.



4. Shut off Heater Power. Allow system to cool.




5. Relieve pressure, page 24.
6. Disconnect heater and motor power cords.


## Remove Supply Tank

|  |  |  |  |  |  |
|--|--|--|--|--|--|
|  |  |  |  |  |  |
|--|--|--|--|--|--|

1. See **Before Beginning Repair**, page 40.
2. Relieve pressure, page 24.
3. Flush, page 26.
4. Place waste container under y-strainer.
5. Close fluid valve (V).




6. Remove filter drain hex nut (N) and drain material.
7. Remove recirculation tubes (P) and place in waste containers.





8. Disconnect swivel elbow at pump fluid inlet.
9. Remove six screws (28) holding tank (27) to cart frame.




10. Loosen nut and slide tank level sensor (S) away from the tank.
11. Pivot top of tank to side and remove the tank, with fluid inlet fittings, off the cart.
12. Reinstall in reverse order. Torque screws (28) to 125 in.-lbs (14 N•m).

## Replace Recirc/Spray Valves



1. See **Before Beginning Repair**, page 40.
2. Relieve pressure, page 24.
3. See FIG. 7. Disassemble Recirc/Spray valves. Clean and inspect all parts for damage.
4. Ensure that the seat (453a) and gasket (453b) are positioned inside each valve cartridge (453).
5. Apply PTFE pipe sealant to all tapered pipe threads before reassembling.
6. Reassemble in reverse order, following all notes in FIG. 7.



- ⚠ Torque to 250 in-lb (28 N•m).
- ⚠ Use blue threadlocker on valve cartridge threads into manifold.
- ⚠ Part of item 453.


**FIG. 7: Recirc/Spray Valves**

## Displacement Pump

**NOTE:** Use dropcloth or rags to protect Reactor and surrounding area from spills.



1. See **Before Beginning Repair**, page 40.
2. Relieve pressure, page 24.
3. Close both fluid valves (V).



**NOTE:** Use dropcloth or rags to protect Reactor and surrounding area from spills.

4. Open filter drain hex nut (N) on y-strainer.

### Remove Intake Valve Only

**NOTE:** If pump is not generating any pressure, the intake ball check may be stuck closed with dried material.


If the pump is not generating pressure on the down-stroke, intake ball check may be stuck open.


Either of these conditions can be serviced with the pump in place.


5. Disconnect fluid inlet (C) and swing it aside.
6. Remove intake valve by hitting ears (E) firmly, right-to-left, with a non-sparking hammer. Unscrew from pump. See displacement pump manual for repair and parts.


### Remove Entire Pump Assembly

7. Disconnect fluid inlet (C) and outlet (D) lines. Also disconnect steel outlet tube (46) from heater inlet.

8. Remove pump rod cover (222). Push clip up in back and push pin (217) out. Loosen locknut (218) by hitting firmly right-to-left with a non-sparking hammer. Unscrew pump. See manual 311076 for pump repair and parts.
9. Install pump in reverse order of disassembly, following all notes in FIG. 8. Clean strainer (51). Reconnect fluid inlet (C) and outlet (D) lines.
10. Tighten fluid outlet fitting (D), then tighten locknut (218) by hitting firmly with a non-sparking hammer.
11. Set function knob to Slow Recirc . Purge air and prime. See **Purge Air and Flush Fluid From Lines**, page 19.




 Flat side faces up. Tighten by hitting firmly with non-sparking hammer.

 Lubricate threads with ISO oil or grease.

**FIG. 8: Displacement Pump**

## Control Panel


### Replace Temperature Display



#### NOTICE

Before handling board, put on a static conductive wrist strap to protect against static discharge which can damage board. Follow instructions provided with wrist strap.

1. See **Before Beginning Repair**, page 40.
2. Remove screws (21) and display cover (26).




3. Put on static conductive wrist strap.
4. Disconnect main display cable (81) from upper right corner of temperature display (353). See FIG. 10.
5. Remove jumper (373) from back of display (353). Set aside and install jumper on new display.
6. Disconnect ribbon cable(s) (R) from back of display; see FIG. 10.
7. Remove nuts (360) from plate (351).
8. Disassemble display (353), see detail in FIG. 10.
9. Reassemble in reverse order, see FIG. 10. Apply medium strength thread sealant where shown.


### Replace Function Knob/Potentiometer



1. See **Before Beginning Repair**, page 40.
2. Remove screws (21) and back cover (26).
3. Disconnect potentiometer wires from J5 on motor control board (354). See FIG. 12, page 46.
4. See FIG. 9. Remove two setscrews (356a) and pull function knob (356) off potentiometer (357) shaft.
5. Remove nut (N, part of 357) and detent plate (358).
6. Install new potentiometer (357) in reverse order. Position potentiometer so slot (S) is horizontal. Position knob (356) so pointer (P) faces up. Install knob on shaft so slot (S) engages alignment pin in knob. Push knob onto shaft against detent spring before tightening setscrews (356a).
7. Reconnect potentiometer wires to J5.



**FIG. 9: Function Knob/Potentiometer**



**FIG. 10: Control Panel**

# Motor Control

## Power Bootup Check

**NOTE:** Power must be on to check. See FIG. 11 or location. Function is:

- Motor ready: LED on.
- Motor not ready: LED off.
- Status code (motor not running): LED blinks status code.
- Multiple status codes are separated by a longer LED off duration.

## Control Board LEDs

If LEDs on bottom board are on and the top board LEDs are off, the following may have occurred:

- A pressure transducer shorted out.
- A short occurred between the power and ground pin of the potentiometer.

| Board  | LED | State     | Description                  |
|--------|-----|-----------|------------------------------|
| Top    | R4  | Red: on   | Hardware or software failure |
|        | G1  | Green: on | Power on                     |
| Bottom | D4  | Red: on   | Hardware or software failure |
|        | D16 | Green: on | Power on                     |





FIG. 11

## Replace Control Board



**NOTE:** Check motor before replacing board. See **Test Motor**, page 54.


1. See **Before Beginning Repair**, page 40.
2. Remove access cover (26) on back of cart to expose control board (354).



3. Disconnect all cables and connectors from board (354). See Table 8, page 46.
4. Remove six nuts (363) and remove board from control board (354). See FIG. 10, page 44.
5. Install new board in reverse order.

**Table 8: Control Board Connectors (see FIG. 12)**

| Top Board Connectors |     |                           | Bottom Board Connectors        |             |
|----------------------|-----|---------------------------|--------------------------------|-------------|
| Board Jack           | Pin | Description               | Connector                      | Description |
| J1                   | n/a | Not Used                  | Female Quick Connect Terminals | Power       |
| J2                   | n/a | Not Used                  | Plug Housing with Male Blades  | Motor Power |
| J3                   | n/a | Error LED                 |                                |             |
| J4                   | n/a | Tank Level LED            |                                |             |
| J5                   | n/a | Function Knob             |                                |             |
| J6                   | 1   | Brown - ISO Sensor V+     |                                |             |
|                      | 2   | Blue - ISO Sensor V-      |                                |             |
|                      | 3   | Black - ISO Sensor Signal |                                |             |
|                      | 4   | Brown - RES Sensor V+     |                                |             |
|                      | 5   | Blue - RES Sensor V-      |                                |             |
|                      | 6   | Black - RES Sensor Signal |                                |             |
| J8                   | n/a | Boost Power Relay         |                                |             |
| J9                   | n/a | Motor Overtemperature     |                                |             |
| J10                  | n/a | Cycle Switch              |                                |             |
| J11                  | n/a | ISO Pressure Transducer   |                                |             |
| J12                  | n/a | RES Pressure Transducer   |                                |             |




**FIG. 12: Wiring Connections**

## Replace Temperature Control Modules

### NOTICE


Before handling assembly put on a static conductive wrist strap to protect against discharge which can damage assembly. Follow instructions provided with wrist strap.

1. See **Before Beginning Repair**, page 40.
2. Remove heater shroud (89) and electronics cover (55).



3. Put on static conductive wrist strap.

4. Disconnect all cables and connectors from temperature control module (59).



**FIG. 13**

5. Remove hex nut (56) and replace defective module.
6. Install new module in reverse order. Connect all cables and connectors.

### Temperature Control Modules Connections

**Table 9: Heater Control Module Connections**

| Connector         | Description                   |            |
|-------------------|-------------------------------|------------|
|                   | 100-120VAC                    | 200-240VAC |
| DATA (A)          | Not used                      |            |
| Sensor (B)        | See Table 11                  |            |
| DISPLAY (C)       | Display                       |            |
| COMMUNICATION (D) | Communication to power boards |            |
| PROGRAM (E)       | Software programming          |            |
| BOOT (F)          | Software bootloader           |            |

**Table 9: Heater Control Module Connections**


| Connector       | Description  |            |
|-----------------|--|------------|
|                 | 100-120VAC   | 200-240VAC |
| POWER/RELAY (G) | Circuit board power input and contactor control output |            |

**Table 10: Temperature Power Module Connections**

| Connector         | Description                    |
|-------------------|--------------------------------|
| COMMUNICATION (H) | Communication to control board |
| POWER (J)         | Power to heater                |

**Table 11: Sensor B Connections**

| 100-120VAC |      | 200-240VAC |          | Description                  |
|------------|------|------------|----------|------------------------------|
| Connector  | Pin  | Connector  | Pin      |                              |
| B1         | 1, 2 | B1         | 1, 2     | Overtemperature Switch       |
| B2         | 1    | B1         | 5        | Thermocouple ISO, R (red)    |
| B2         | 2    | B1         | 6        | Thermocouple ISO, Y (yellow) |
| B2         | 4    | B1         | 8        | Thermocouple RES, R (red)    |
| B2         | 5    | B1         | 9        | Thermocouple RES, Y (yellow) |
| B2         | 3    | B1         | 3-4,7,10 | Unused                       |



**FIG. 14: Temperature Control Module Connections**




# Heater

## Test Heater Element



1. See **Before Beginning Repair**, page 40.
2. Wait for heater to cool.
3. Remove heater shroud (90) and electronics cover (55).



ti21845a

**FIG. 15**

4. Disconnect heater element wires from heater wire connector. Test with ohmmeter. Replace heater element if the resistance reading does not fall within the range.

| Nominal Heater Voltage | Heater Wattage Per Zone | Element Wattage | Ohms  |
|------------------------|-------------------------|-----------------|-------|
| 120                    | 1500                    | 500             | 24-32 |
|                        |                         | 1000            | 12-16 |
| 230                    | 2000                    | 620             | 73-94 |
|                        |                         | 1380            | 32-43 |

## Remove Heater Element

1. To remove heater element (307), first remove thermocouple (310) to avoid damage, see step 7, page 50.
2. Remove heater element (307 or 316) from housing (301). Be careful not to spill any fluid left in housing.
3. Inspect element.

**NOTE:** It should be relatively smooth and shiny. If there is a crusted, burnt, ash-like material adhered to element or sheath shows pitting marks, replace element.

4. Install new heater element (307 or 316). Hold mixer (309) so it does not block thermocouple port (P), for (307) only.
5. Reinstall thermocouple, page 50.
6. Reconnect heater element leadwires to heater wire connector.
7. Replace heater shroud (90) and electronics cover (55).

## Line Voltage

The primary heaters output their rated wattage at their nominal voltage of either 120VAC or 230VAC, depending on system. Low line voltage will reduce power available and the heaters will not perform at full capability.


## Thermocouple

1. See **Before Beginning Repair**, page 40.



2. Wait for heaters to cool.
3. Remove heater shroud (90) and electronics cover (55). See FIG. 15, page 49.
4. Loosen and remove temperature control module bracket mounting fasteners (56). Move control module up and out of the way to access thermocouple.
5. Disconnect thermocouple wires from B on temperature control module. See **Temperature Control Modules Connections**, page 48.
6. Clip cable ties as necessary. Note path as wires must be replaced in the same way.
7. See FIG. 16. Loosen ferrule nut (N). Remove thermocouple (310) from heater housing (301), then remove thermocouple housing (H). Do not remove the thermocouple adapter (305) unless necessary. If adapter must be removed, ensure that mixer (309) is out of the way when replacing the adapter.

8. Replace thermocouple, FIG. 16.
  - a. Remove protective tape from thermocouple tip (T).
  - b. Apply PTFE tape and thread sealant to male threads and tighten thermocouple housing (H) into adapter (305).
  - c. Push in thermocouple (310) so tip (T) contacts heater element (307).
  - d. Holding thermocouple (T) against heater element, tighten ferrule nut (N) 1/4 turn past tight.
9. Route wires (S) into cart and thread into bundle as before. Reconnect wires to board.
10. Replace heater shroud (90) and electronics cover (55). See FIG. 15, page 49.
11. Turn on heaters ISO and RES simultaneously to test. Temperatures should rise at same rate. If one heater is low, loosen ferrule nut (N) and tighten thermocouple housing (H) to ensure thermocouple tip (T) contacts element (307).



ti7924a

**FIG. 16. Thermocouple**

## Overtemperature Switch

1. See **Before Beginning Repair**, page 40.




2. Wait for heaters to cool.
3. Remove heater shroud (90) and electronics cover (55). See FIG. 15, page 49.
4. Disconnect one leadwire from overtemperature switch (308), FIG. 16. Test across switch with ohmmeter. Resistance must be approximately 0 ohms.
5. If switch fails test, remove wires and screws. Discard failed switch. Apply thermal compound 110009, install new switch in same location on housing (301), and secure with screws (311). Reconnect wires.


**NOTE:** If wires need replacement, disconnect from heater control module. See FIG. 24 on page 74.

## Pressure Transducers

1. See **Before Beginning Repair**, page 40.




2. Remove back cover (26).



3. Disconnect transducer cables from J11 and J12 connectors. Reverse ISO and RES transducer connections and check if status codes follows the bad transducer.

4. Replace transducer if the transducer fails test.
  - a. Remove supply tank, page 40.
  - b. Follow transducer cable on cart frame and cut zip ties. Disconnect transducer from pump outlet manifold.
  - c. Install o-ring (553) on new transducer (554). Apply lubricant to o-ring (553).
  - d. Install transducer (554) in manifold. Mark end of cable with tape (red = ISO, blue = RES).
  - e. Route cable back through cart frame to the control board. See FIG. 12, page 46.
  - f. Install supply tank.



ti21846a

**FIG. 17. Transducer**

## Drive Housing



### Removal

1. See **Before Beginning Repair**, page 40.
2. Remove screws (207) and end covers (229), see FIG. 18.

**NOTE:** Examine connecting rod (216). If rod needs replacing, first remove the pump (219), page 42.

#### NOTICE

To prevent equipment damage, do not drop gear reducer (214) and crankshaft (210) when removing drive housing (215). These parts may stay engaged in motor end bell (MB) or may pull away with drive housing.

3. Disconnect pump inlet and outlet lines. Remove screws (220) and pull drive housing (215) off motor (201). Connecting rod (216) will disengage from crankshaft (210).
4. Examine crankshaft (210), gear reducer (214), thrust washers (208, 212), and bearings (209, 211, 213).

### Installation

1. Apply grease liberally to washers (208, 212), bearings (209, 211, 213), gear reducer (214), crankshaft (210), and inside drive housing (215). Grease is supplied with replacement parts kits.

**NOTE:** RES side crankshaft (210) includes the cycle counter magnet (224). When reassembling, be sure to install crankshaft with magnet on RES side.

If replacing crankshaft, remove magnet (224). Reinstall magnet in center of offset shaft on new crankshaft. Position shaft in Park position.

2. Install bronze bearings (211, 213) in drive housing (215), as shown.
3. Install bronze bearings (209, 211) and steel washer (208) on crankshaft (210). Install bronze bearing (213) and steel washer (212) on gear reducer (214).

4. Install gear reducer (214) and crankshaft (210) into motor end bell (MB).


**NOTE:** Crankshaft (210) must be in line with crankshaft at other end of motor. Pumps will move up and down together.

**NOTE:** If connecting rod (216) or pump (219) were removed, reassemble rod in housing and install pump, page **Displacement Pump**, page 42.


5. Push drive housing (215) onto motor (201). Install screws (220).
6. Install drive housing covers (229) and screws (207). Pumps must be in phase (both at same position in stroke).

# Replace Cycle Counter Switch


**NOTE:** RES side drive housing cover (229) includes the cycle counter switch (223), mounted in the cover. When reassembling, be sure to install cover with switch on RES side.



T17028a



ti21847a

 Crankshaft must be in line with crankshaft at other end of motor, so pumps move up and down in unison.

**FIG. 18. Drive Housing**

## Electric Motor

### Test Motor

If motor is not locked up by pumps, it can be tested using a 9 V battery.

1. Open recirculating valves.
2. Disconnect motor connections from control board, see FIG. 12, page 46. Touch jumpers from battery to motor connections. Motor should turn slowly and smoothly.

### Removal

**NOTE:** See wiring schematic, page 46.



1. See **Before Beginning Repair**, page 40.
2. Relieve pressure, page 24.
3. Remove four screws (91), shroud (89), and mounting brackets (233). See FIG. 18.
4. Remove fans (16) and disconnect cable (80). See FIG. 20.
5. Remove drive housing/pump assemblies, page 52.
6. Remove display control cover (26). Disconnect motor cables as follows:
  - a. Unplug motor power connector before ferrite (88).
  - b. Unplug motor temp switch harness from connector J9 and remove grounding cable from grounding screw.
7. Remove RES supply tank. See **Remove Supply Tank**, page 40.
8. Cut zip ties.
9. Thread motor power switch harness and over temp switch out bottom of control module and cable channel, to free motor.

### NOTICE

To prevent dropping the motor, two people may be required to lift.

10. Remove screws (15) holding motor (201) to bracket. Lift motor off unit.
11. If replacing motor, remove shroud mounting bolts (207) and brackets (233) and set aside.

### Installation

1. If replacing motor, install fan assemblies (16) and shroud mounting brackets (233) on new motor (201).
2. Place motor (201) and fans (16) on unit. Thread motor switch harness through grommets in cart and into the back of the display. See FIG. 24 on page 74.
3. Fasten motor (201) with screws (15) underneath. Do not tighten yet.
4. Plug motor temp switch harness to connector J9 and grounding cable from grounding screw.
5. Plug in motor power connector.
6. Secure all cables to cart frame with zip ties.
7. Install display control cover (26).
8. Install supply tank.
9. Install drive housing/pump assemblies, page 52. Reconnect inlet assemblies to pumps.
10. Torque screws (15) to 150 in.-lbs (17 N•m).
11. Return to service.

## Motor Brushes


**NOTE:** Replace brushes worn to less than 1/2 in. (13 mm). Brushes wear differently on each side of motor; check both sides. Brush Repair Kit 287735 is available; kit includes instruction sheet 406582.

**NOTE:** Motor commutator should be smooth. If not, resurface commutator or replace motor.



1. See **Before Beginning Repair**, page 40.
2. Relieve pressure, page 24.
3. Remove four screws (91) and motor shroud (89). See FIG. 18.
4. Remove fans (16) and disconnect cable (80). See FIG. 20.
5. Loosen pump inlet and outlet connections.
6. Remove the display control cover (26). Disconnect motor cables as follows:
  - a. Unplug motor power connector.
  - b. Unplug motor temp switch harness from connector J9. Disconnect grounding cable from grounding screw.
7. To replace the front motor brush:
  - a. Remove the two bolts and access cover plate. See FIG. 19.
  - b. Remove old brushes and install new ones supplied in kit.
8. To replace the rear motor brush:
  - a. Remove motor mounting bolts. Slide the motor forward and lean on the cart frame.
  - a. Remove the two bolts and access cover plate. See FIG. 19.
  - b. Remove old brushes and install new ones supplied in kit.


9. See instruction sheet 406582, included with Brush Repair Kit 287735.



**FIG. 19: Motor Brushes**

## Fans

1. Disconnect fan cable (80) from fan (16). With Motor Power on, test cable connector for line voltage (100-120VAC or 200-240VAC).
2. *If voltage is within the described range for that system, fan is defective. Remove screws holding fan to shield (17). Install new fan in reverse order.*
3. *If voltage is not within the appropriate range, check fan cable connection at terminal blocks 1 and 2; see FIG. 23 on page 73.*




**FIG. 20: Fans**

## Tank Fluid Level Sensors

### Adjust


Adjust position of tank fluid level sensor (57) so that the sensor contacts the surface of the tank.

1. Loosen sensor jam nuts and press sensor (57) against the tank.
2. Spin on inner jam nut until flush, then tighten inner jam nut one more turn.
3. Retighten outer jam nut.



### Replace

1. Loosen jam nuts and remove level sensor assembly (57).
2. Remove supply tank, see page 40.
3. Cut zip ties securing the sensor cable to the cart.
4. Remove the display control cover (26).




5. Disconnect level sensor connector from J6 on control board. See FIG. 12, page 46.

6. Route new tank level sensor cable through grommet on bottom of cart and through the grommet on bottom of control panel. Connect new level sensor (57) to J6.
7. Install the display control cover (26).
8. Zip tie tank level sensor cable with other low voltage cables.
9. Reinstall supply tank. See page 40.
10. Adjust position of level sensor assembly (57). See **Adjust**.
11. Set sensitivity. See **Reset Sensitivity**, page 57.
12. Check operation of both sensors.
  - a. Hold one hand inside both tanks for 5 seconds, near inner wall, where the tank level sensor is located.
  - b. The tank level indicator LED on the control panel will stop flashing when it senses both of your hands.
  - c. The tank level indicator LED will flash if either tank sensor indicates that it is low. Alternately, remove each hand away from inner wall for 5 seconds. The tank level indicator LED on the control panel will flash.

**Table 12: Sensor LED Identification**

| LED          | Status   |
|--------------|--|
| Green - on   | Sensor is powered  |
| Green - off  | Sensor is not powered                                    |
| Yellow - on  | Sensor detects material (immediate, no 5 second display) |
| Yellow - off | Sensor does not detect material                          |



**FIG. 21: Sensor LEDs**




## Reset Sensitivity

The tank fluid level sensor sensitivity may need to be adjusted when:

- A new tank has a different insulation density than the previous tank.
- Material build-up is on the inside or outside of the tank. Adjust sensitivity rather than thoroughly cleaning the tank.
- Level sensor sensitivity comes out of alignment through misuse or harsh environment.
- Material density is less than normally pumped materials.

1. Ensure tank is completely empty.
2. Remove shroud (89) to expose the sensors.
3. Ensure sensor (57) and tank are properly installed. See **Adjust**, page 56.
4. Locate the adjustment screw (S) above the green and yellow LEDs.

**NOTE:** The adjustment screw on some tank level sensors is covered by white tape. Remove the white tape to access the adjustment screw.



**Fig. 22: Adjustment Screw**

5. Use a small flathead screwdriver and slowly turn the adjustment screw (S) clockwise until the yellow LED turns on.
6. Slowly turn the adjustment screw (S) counterclockwise until the yellow LED barely turns off.

7. Slowly turn the adjustment screw (S) counterclockwise an additional 1/2 turn.

**NOTE:** The yellow LED should stay turned off.

8. Fill tank with desired material and verify that sensor detects material. The yellow LED will turn on when material reaches the one gallon mark.


If the yellow LED does not turn on after two gallons of the material, then the material density may be too low and is not detected by the sensor. Turn the adjustment screw clockwise in 1/8 turn increments until sensor detects the material and the yellow LED turns on.

**NOTE:** If the adjustment screw is turned a total 1/2 turn, then it will not detect an empty tank.

9. Reinstall the shroud (89).

# Parts

## System Packages




| System Package | Proportioner       | Hose               | Gun     | Power Cord Adapter |                |
|----------------|--------------------|--------------------|---------|--------------------|----------------|
|                | 101<br>see page 59 | 102<br>see page 72 | 103     | 104                |                |
|                |                    |                    |         | Part No.           | Region         |
| APT100         | 24T100             | 25R000             | 249810  | ✘                  | ✘              |
| P2T100         | 24T100             | 25R000             | GCP2RA* | ✘                  | ✘              |
| APT900         | 24R900             | 25R000             | 249810  | 16W239             | North America  |
| APT901         | 24R900             | 25R000             | 249810  | 15G958             | Europe         |
| APT902         | 24R900             | 25R000             | 249810  | 15G962             | Australia/Asia |
| P2T900         | 24R900             | 25R000             | GCP2RA* | 16W239             | North America  |
| P2T901         | 24R900             | 25R000             | GCP2RA* | 15G958             | Europe         |
| P2T902         | 24R900             | 25R000             | GCP2RA* | 15G962             | Australia/Asia |

\* Probler packages use recirc accessory kit 24E727.


✘ Not included.

# E-10hp Proportioners


24T100, 100-120VAC, Proportioner  
24R900, 200-240VAC, Proportioner



ti21853b



ti21855b



ti21854a

Parts

- △ Apply sealant to all non-swiveling pipe threads.
- △ Apply sealant to threads of nut cap.
- △ Apply lubricant to thread and axle of cart.
- △ Apply even distribution of thermal grease on bottom of metal surface of solid state relays.
- △ Torque to 125 in.-lbs (14 N•m).
- △ Torque to 150 in.-lbs (17 N•m).
- △ Assemble nut to finger tight only.
- △ Orient SSR with terminals 1 and 2 towards the top.
- △ Orient fan to flow down and connector plug towards the back.
- △ Orient heater module with fins outwards.
- △ Assemble sensor flush to tank surface.
- △ Install clamp-on ferrite near termination of transducer wires. See FIG. 24, page 74.
- △ Install clamp-on ferrite on black and red motor power wires. See FIG. 24, page 74.

**24T100, 100-120VAC, Proportioner**  
**24R900, 200-240VAC, Proportioner**

| Ref. | Part   | Description                            | Quantity                  |                           |
|------|--------|--|---------------------------|---------------------------|
|      |        |  | 24T100,<br>100-120<br>VAC | 24R900,<br>200-240<br>VAC |
| 1    | ---    | CART                                   | 1                         | 1                         |
| 2    | 24T950 | BRACKET, tank mount                    | 1                         | 1                         |
| 3    | 24T951 | BRACKET, crossbar                      | 1                         | 1                         |
| 4    | 24T952 | BRACKET, gusset, cart                  | 1                         | 1                         |
| 5    | 24T953 | BRACKET, motor mount                   | 1                         | 1                         |
| 6    | 110996 | NUT, hex, flange head                  | 18                        | 18                        |
| 7    | 101765 | GROMMET                                | 3                         | 3                         |
| 8    | 119975 | GRIP, vinyl, gray; 1.25 in.            | 2                         | 2                         |
| 9    | 154636 | WASHER, flat                           | 4                         | 4                         |
| 10   | 116411 | SPRING, compression                    | 2                         | 2                         |
| 11   | 116477 | WASHER, flat, nylon                    | 4                         | 4                         |
| 12   | 116478 | WHEEL, pneumatic                       | 2                         | 2                         |
| 13   | 101242 | RING, retaining, ext.                  | 2                         | 2                         |
| 14   | 24T954 | PROPORTIONER, see page 66              | 1                         | 1                         |
| 15   | 117493 | SCREW, mach, hex washer hd; 1/4-20     | 4                         | 4                         |
| 16   | 24K985 | FAN, cooling, 120 VAC                  | 2                         |                           |
|      | 24K986 | FAN, cooling, 230 V                    |                           | 2                         |
| 17   | 115836 | GUARD, finger                          | 2                         | 2                         |
| 18   | 120094 | SCREW, pan hd, phil, zinc              | 8                         | 8                         |
| 19   | 24U009 | HEATER, assy; 120V, 1000W; see page 68 | 1                         |                           |
|      | 24T955 | HEATER, assy; see page 68              |                           | 1                         |
| 20   | 167002 | INSULATOR, heat                        | 2                         | 2                         |
| 21   | 108296 | SCREW, mach, hex wash hd               | 10                        | 10                        |
| 22   | 24T960 | MANIFOLD, outlet/recirc; see page 71   | 1                         | 1                         |
| 23   | 24T962 | DISPLAY, control; see page 69          | 1                         | 1                         |
| 24   | 117623 | NUT, cap; 3/8-16                       | 4                         | 4                         |
| 25   | 24U005 | DIODE, light-emitting, 120 V           | 1                         |                           |
|      | 24T970 | DIODE, light-emitting, 230 V           |                           | 1                         |

| Ref. | Part   | Description   | Quantity                  |                           |
|------|--------|---|---------------------------|---------------------------|
|      |        |   | 24T100,<br>100-120<br>VAC | 24R900,<br>200-240<br>VAC |
| 26   | 24R648 | COVER, display  | 1                         | 1                         |
| 27   | 24T973 | TANK  | 2                         | 2                         |
| 28   | 111800 | SCREW, cap, hex hd  | 12                        | 12                        |
| 29   | 127148 | SCREW, set, 7/16-14, 1/2, black                               | 2                         | 2                         |
| 30   | 24T975 | LID; includes o-ring (30a)                                    | 2                         | 2                         |
| 30a  | 24T974 | O-RING  | 2                         | 2                         |
| 31   | 24K976 | MUFFLER, 1/4 NPT  | 1                         | 1                         |
| 32   | 101044 | WASHER, plain   | 1                         | 1                         |
| 33   | 119973 | CABLE, sst lanyard; 14 in.                                    | 2                         | 2                         |
| 35   | 24K984 | DRYER, desiccant, mini in-line                                | 1                         | 1                         |
| 36   | 162453 | FITTING; 1/4 npsm x 1/4 npt                                   | 1                         | 1                         |
| 37   | 100176 | BUSHING, hex  | 1                         | 1                         |
| 38   | 24K977 | FILTER, regulator, air; with 3/8 npt auto drain; includes 64a | 1                         | 1                         |
| 38a  | 15D909 | ELEMENT, 5 micron; polypropylene; not shown                   | 1                         | 1                         |
| 39   | 157350 | ADAPTER   | 1                         | 1                         |
| 40   | 104641 | FITTING, bulkhead   | 1                         | 1                         |
| 41   | 169970 | FITTING, line air; 1/4-18 npt                                 | 1                         | 1                         |
| 42   | 116704 | ADAPTER, 9/16-18 JIC x 1/4 NPT                                | 4                         | 4                         |
| 43   | 117506 | FITTING, swivel, 1/4 npt x #6 JIC                             | 2                         | 2                         |
| 44   | ---    | MANIFOLD, assembly, outlet; see page 72                       | 2                         | 2                         |
| 45   | 556765 | FITTING, #6 JIC 1/4PM   | 2                         | 2                         |
| 46   | 24T977 | TUBE, pump outlet, ISO  | 2                         | 2                         |
| 47   | 24T978 | TUBE, heater outlet, ISO                                      | 2                         | 2                         |
| 48   | 24T979 | HOSE, coupled, recirc, ISO                                    | 1                         | 1                         |
| 49   | 24T980 | TUBE, recirculation   | 2                         | 2                         |
| 50   | 24T981 | HOSE, coupled, recirc, RES                                    | 1                         | 1                         |

Parts

| Ref. | Part   | Description                          | Quantity                  |                           |
|------|--------|--------------------------------------|---------------------------|---------------------------|
|      |        |                                      | 24T100,<br>100-120<br>VAC | 24R900,<br>200-240<br>VAC |
| 51   | 114225 | TRIM, edge protection                | 1                         | 1                         |
| 52   | 119992 | FITTING, pipe, nipple, 3/4 x 3/4 npt | 2                         | 2                         |
| 53   | 24T982 | MANIFOLD, inlet, RES; see page 70    | 1                         | 1                         |
| 54   | 24T986 | MANIFOLD, inlet, ISO; see page 70    | 1                         | 1                         |
| 55   | 24T987 | COVER, electronics                   | 1                         | 1                         |
| 56   | 115942 | NUT, hex, flange head                | 12                        | 12                        |
| 57   | 24T988 | SENSOR, tank level                   | 2                         | 2                         |
| 58   | 24T990 | PANEL, heater control mount          | 2                         | 2                         |
| 59   | 247828 | MODULE, heater                       | 2                         | 2                         |
| 60   | 24T989 | PANEL, logic control mount           | 1                         | 1                         |
| 61   | 24T308 | MODULE, heater control, 120 V        | 1                         |                           |
|      | 24T307 | MODULE, heater control, 230V         |                           | 1                         |
| 64   | 24U006 | RELAY, SSR, 120 V                    | 2                         |                           |
|      | 24T991 | RELAY, SSR, 230 V                    |                           | 2                         |
| 65   | 112144 | SCREW, mach, pan hd                  | 4                         | 4                         |
| 66   | 126811 | BLOCK, clamp end                     | 4                         | 4                         |
| 67   | 24U007 | CONNECTOR, contactor; 120 V          | 1                         |                           |
|      | 24T992 | CONNECTOR, contactor; 230 V          |                           | 1                         |
| 68   | 126817 | COVER, end                           | 1                         | 1                         |
| 69   | 126818 | BLOCK, terminal 3-wire               | 2                         | 2                         |
| 70   | 126810 | RELAY, cradle                        | 1                         | 1                         |



| Ref. | Part   | Description                                 | Quantity                  |                           |
|------|--------|---|---------------------------|---------------------------|
|      |        |   | 24T100,<br>100-120<br>VAC | 24R900,<br>200-240<br>VAC |
| 71   | 24T993 | RELAY, 12V                                  | 1                         | 1                         |
| 72   | 255043 | HOLDER, fuse terminal block; 5 x 20mm       | 2                         | 2                         |
| 73   | 255023 | FUSE, 5A, 5 x 20 mm                         | 2                         | 2                         |
| 74†  | 127239 | CONNECTOR, 5 pin                            | 1                         |                           |
|      | 127240 | CONNECTOR, 10 pin                           |                           | 1                         |
| 75†  | 120748 | CONNECTOR, 2 pin                            | 2                         | 1                         |
| 76   | 127237 | CONNECTOR, 6 pin                            | 1                         | 1                         |
| 77   | 116171 | BUSHING, strain relief                      | 2                         |                           |
|      | 16W761 | BUSHING, strain relief                      |                           | 2                         |
| 78✖† | 24T994 | HARNESS, POWER; see FIG. 23 on page 73.     | 1                         | 1                         |
| 79✖† | 24T995 | CABLE, communication, heater control module | 1                         | 1                         |
| 80✖† | 24T996 | CABLE, FAN, 29 in. (736.6 mm)               | 2                         | 2                         |
| 81✖† | 24T997 | CABLE, control, display                     | 1                         | 1                         |
| 82✖† | 24T998 | CABLE, harness, overtemperature             | 1                         | 1                         |
| 83   | 24T999 | CONNECTOR, jumper                           | 2                         | 2                         |
| 84   | 24U008 | CORD, 20A, 120 V                            | 2                         |                           |
|      | 24U000 | CORD, 16A, 230 V                            |                           | 2                         |
| 85   | 113505 | NUT, keps, hex hd                           | 2                         | 2                         |
| 88✖† | 125835 | CLIP, ferrite bead                          | 2                         | 2                         |
| 89   | 24U001 | COVER, proportioner, lower                  | 1                         | 1                         |
| 90   | 24U002 | COVER, proportioner, upper                  | 1                         | 1                         |
| 91   | 115492 | SCREW, mach, slot hex wash hd               | 10                        | 10                        |
| 92   | 24U003 | GUARD, splash, hose rack                    | 1                         | 1                         |
| 93   | 24U004 | RACK, hose                                  | 1                         | 1                         |
| 94   | 120008 | PLUG, tube                                  | 4                         | 4                         |
| 95   | 120150 | ISOLATOR, pad, rubber                       | 2                         | 2                         |
| 96   | 119999 | BOLT, shoulder                              | 2                         | 2                         |
| 97   | 110533 | WASHER, flat, nylon, 1/4                    | 4                         | 4                         |
| 98▲  | 15G280 | LABEL, safety, warning, multiple            | 1                         | 1                         |
| 99▲  | 189930 | LABEL, electric shock                       | 2                         | 2                         |
| 104  | 217374 | LUBRICANT, ISO pump                         | 1                         | 1                         |


▲ Replacement Danger and Warning labels, tags, and cards are available at no cost.

✖ Not shown.

† See FIG. 23 on page 73.

--- Not available for purchase.

## 24T954, 100-120VAC and 200-40VAC Bare Proportioner



- 1 Apply lubricant to all gear teeth, motor pinion, and motor endbell on both sides of motor.
- 2 Apply lubricant to rectangular cavity on connecting link.
- 3 Apply lubricant to threads of pump cylinder before assembly into housing. Align top of cylinder flush within 0.06 to inside bottom of pump mounting hole.
- 4 Torque fasteners to 140-160 in.-lbs (15-18 N•m).
- 5 Assemble nut to finger tight only.

- 6 Torque fasteners to 30-35 in.-lbs. Applies only when fasteners are assembled in plastic housings (215).
- 7 Switch mounts to cover opposite brush end of motor only.
- 8 Housing must be installed on motor with crankshafts aligned with each other.
- 9 Assemble magnet to center of offset crankshaft on switch cover side of motor and adjust for park location.
- 10 Affix switch to motor cover with double-sided tape. Cut to 2 in. (50.8 mm). Mount cover on side opposite brush end of motor.

| Ref. | Part   | Description  | Qty |
|------|--------|--|-----|
| 201  | 24T758 | MOTOR, electric                                    | 1   |
| 207‡ | 115492 | SCREW, mach, slot hex wash<br>hd                   | 10  |
| 208* | 116074 | WASHER, thrust                                     | 2   |
| 209* | 107434 | BEARING, thrust                                    | 2   |
| 210* | 300001 | KIT, crankshaft                                    | 2   |
| 211* | 180131 | BEARING, thrust                                    | 2   |
| 212‡ | 116073 | WASHER, thrust                                     | 2   |
| 213‡ | 116079 | BEARING, thrust                                    | 4   |
| 214‡ | 244242 | GEAR, reducer (first stage)                        | 2   |
| 215‡ | 287055 | HOUSING, drive                                     | 2   |
| 216◆ | 287053 | KIT, repair, connecting, rod                       | 2   |
| 217◆ | 196762 | PIN, straight                                      | 2   |
| 218  | 195150 | NUT, jam, pump                                     | 2   |
| 219  | 24L006 | PUMP, displacement                                 | 2   |
| 220‡ | 117493 | SCREW, mach, hex washer hd                         | 8   |
| 221‡ | 300002 | KIT, cover; includes switch                        | 1   |
| 222‡ | 15B589 | COVER, pump rod                                    | 2   |
| 223  | 117770 | SWITCH, reed with cable                            | 1   |
| 224  | 24K982 | MAGNET, disc, 0.38 dia.,<br>0.100 thick; not shown | 1   |
| 227  | 115711 | TAPE, foam, 1/2 wide                               | 1   |
| 229  | 300003 | KIT, cover   | 1   |
| 233  | 16W162 | BRACKET, shroud tab                                | 2   |


\* Included in 300001 Crankshaft Kit (210).

‡ Included in 244242 Gear Reducer Kit (214).

‡ Included in 287055 Drive Housing Kit (215).

◆ Included in 287053 Connecting Rod Kit (216).

## 24U009, 100-120VAC Heater 24T955, 200-240VAC Heater



ti21850a

⚠️ 1 Torque to 120 ft-lbs (163 N•m).

⚠️ 2 Torque to 23 ft-lbs (31 N•m).

⚠️ 3 Apply 110009 thermal heat sink compound.

⚠️ 4 Apply sealant and tape to all non-swiveling and threads without o-rings.

⚠️ 5 Apply lubricant to o-rings before assembling in heater housing.


⚠️ 6 Tighten NPT fitting from sensor to heater housing as shown. Remove tape from probe tip prior to inserting. Insert probe until tip bottoms on heater element. Tip must touch heating element. Insert ferrule and tighten ferrule nut to sensor probe. Orient sensor as shown and torque 1/4 turn past tight.

| Ref. | Part   | Description                           | Qty. |
|------|--------|---------------------------------------|------|
| 301  | ---    | BLOCK, heater                         | 1    |
| 302  | 15H302 | FITTING, reducer 1-3/16 SAE x 1/2 npt | 4    |
| 303  | 16V432 | FITTING, adapter, #6 JIC x npt, mxm   | 4    |
| 304  | 15H304 | FITTING, plug, 9/16 SAE               | 2    |
| 305  | 15H306 | ADAPTER, thermocouple, 9/16 x 1/8     | 2    |
| 306  | 120336 | O-RING, packing                       | 2    |
| 307  | 24T958 | HEATER, fire rod, 230 V, 24T955 only  | 2    |
|      | 24U012 | HEATER, fire rod, 120 V, 24U009 only  | 2    |

| Ref. | Part   | Description                          | Qty. |
|------|--------|--------------------------------------|------|
| 308  | 15B137 | SWITCH, overtemperature              | 1    |
| 309  | 16U940 | MIXER, heater                        | 4    |
| 310  | 117484 | SENSOR,                              | 2    |
| 311  | ---    | SCREW, mach; #6-32                   | 2    |
| 312  | 124132 | O-RING                               | 4    |
| 316  | 24T959 | HEATER, fire rod, 230 V; 24T955 only | 2    |
|      | 24U014 | HEATER, fire rod, 120 V; 24U009 only | 2    |

--- Not available for purchase.

# 24T962, Display




ti21841a

| Ref. | Part   | Description                          | Qty. | Ref. | Part   | Description                   | Qty.                        |
|------|--------|--------------------------------------|------|------|--------|-------------------------------|-----------------------------|
| 351  | 24T963 | PLATE, display, front                | 1    | 365  | 24T971 | DIODE, light-emitting, yellow | 1                           |
| 352  | 24T964 | ENCLOSURE, control                   | 1    | 366  | ---    | CLAMP, cable                  | 2                           |
| 353  | 24T966 | DISPLAY, heat two zone               | 1    | 367  | 113505 | NUT, keps, hex hd             | 6                           |
| 354  | 24T967 | CONTROL, board, assy                 | 1    | 368  | 101765 | GROMMET                       | 3                           |
| 355  | 24K983 | SWITCH, rocker, w/breaker, 240v, 20a | 2    | 373  | 127019 | CONNECTOR, jumper, e-stop     | 1                           |
| 356  | 24L001 | KNOB, control, w/ball plunger        | 1    |      |        |                               |                             |
| 357  | 24L002 | POTENTIOMETR, adjustment, pressure   | 1    |      |        | ---                           | Not available for purchase. |
| 358  | 15G053 | PLATE, detent, display               | 1    |      |        |                               |                             |
| 359  | 300005 | FILTER, board                        | 2    |      |        |                               |                             |
| 360  | 117523 | NUT, cap (#10)                       | 4    |      |        |                               |                             |
| 361  | 127157 | SCREW, mach, captive, #8             | 8    |      |        |                               |                             |
| 363  | 127158 | NUT, captive, #8                     | 8    |      |        |                               |                             |
| 364  | 24T968 | DIODE, light-emitting, red           | 1    |      |        |                               |                             |


# Fluid Inlets

24T986, ISO Inlet  
 24T982, RES Inlet



ti21851a


- 1 Align Y-strainer as shown
- 2 Apply sealant to all npt threads. Do not apply to JIC threads.
- 3 Apply thermal lubricant to thermometer probe.
- 4 Torque fitting of bent tube to 45-50 ft-lbs (61-67 N•m).
- 5 Align bent tube to fitting within 2°.
- 6 Align thermometer dial as shown.



ti21852a

| Ref. Part | Description                                   | Qty. |
|-----------|---|------|
| 401       | 101078 STRAINER, Y                            | 1    |
| 402       | 15D757 HOUSING, thermometer, Viscon HP        | 1    |
| 403       | 102124 THERMOMETER, dial                      | 1    |
| 404       | 24T983 VALVE, ball, 3/4 npt, mxf, T-handle    | 1    |
| 405       | 24T984 FITTING, adapter JIC-12 X 3/4 npt, mxm | 1    |
| 406       | 24T985 TUBE, assy, inlet                      | 1    |
| 407       | 160327 FITTING, union adapter, 90°            | 1    |

# 24T960, Fluid Manifold




- ▲1 Apply sealant to assembled non-swiveling pipe threads.
- ▲2 Apply sealant and PTFE tape to threads.
- ▲3 Apply sealant to valve threads. Torque to 240-260 in.-lbs (27-29 N•m).
- ▲4 Apply lubricant to mating surfaces of valve base and handle.
- ▲5 Apply lubricant to o-rings on fittings. Torque to 16-20 ft-lbs (22-27 N•m).
- ▲6 Align handles as shown when open.

ti21838a


| Ref. | Part   | Description                        | Qty. | Ref.   | Part   | Description                            | Qty. |
|------|--------|------------------------------------|------|--|--------|--|------|
| 451  | 24T961 | MANIFOLD, fluid                    | 1    | 460  | 127130 | FITTING, straight, JIC-5 x SAE-ORB     | 2    |
| 452  | 102814 | GAUGE, pressure, fluid             | 2    | 461  | 127128 | FITTING, 45° elbow, JIC-5, mxf, swivel | 2    |
| 453  | 239914 | VALVE, drain                       | 2    | 462  | 127131 | FITTING, straight, JIC-6 x SAE-ORB     | 2    |
| 453a | 15E022 | SEAT                               | 1    | 463  | 127129 | FITTING, 45° elbow, JIC-6, mxf, SWIVEL | 2    |
| 453b | 111699 | GASKET                             | 1    | 464▲   | 189285 | LABEL, warning, hot surface            | 1    |
| 454  | 224807 | BASE, valve                        | 2    | ▲ Replacement Danger and Warning labels, tags, and cards are available at no cost. |        |  |      |
| 455  | 187625 | HANDLE, valve, drain               | 2    |  |        |  |      |
| 456  | 111600 | PIN, grooved                       | 2    |  |        |  |      |
| 457  | 16V434 | FITTING, 90 elbow, JIC-6 x SAE-ORB | 2    |  |        |  |      |
| 458  | 119789 | FITTING, elbow, street, 45°        | 2    |  |        |  |      |
| 459  | 162453 | FITTING; 1/4 npsm x 1/4 npt        | 2    |  |        |  |      |

## 25R000, Insulated Hose Bundle with Recirculation Lines



| Ref. | Part   | Description  | Qty | Ref. | Part        | Description  | Qty |
|------|--------|--|-----|------|-------------|--|-----|
| 501  | 24R996 | HOSE, fluid (component ISO), moisture guard; 1/4 in. (6 mm) ID; no. 5 JIC fittings (mxf); 35 ft (10.7 m) | 2   | 503  | 15G342      | HOSE, air; 1/4 in. (6 mm) ID; 1/4 npsm (fbe); 35 ft (10.7 m) | 1   |
| 502  | 24R997 | HOSE, fluid (component RES); 1/4 in. (6 mm) ID; no. 6 JIC fittings (mxf); 35 ft (10.7 m)                 | 2   | 504  | buy locally | TUBE, foam, insulated; 1-3/8 in. (35 mm) ID; 31 ft (9.5 m)   | 1   |
|      |        |  |     | 505  | 156971      | NIPPLE; 1/4 npt; for joining air line to another hose bundle | 1   |

## Outlet Manifold




⚠ Apply lubricant to o-rings.

⚠ Orient housing with exhaust hole pointing down.

| Ref. | Part   | Description                   | Qty |
|------|--------|-------------------------------|-----|
| 551  | 24T976 | MANIFOLD, fluid, pump, outlet | 1   |
| 552  | 247520 | HOUSING, rupture disc         | 1   |
| 553  | 111457 | PACKING, o-ring               | 1   |
| 554  | 24K999 | TRANSDUCER, pressure, control | 1   |





t23356a

Fig. 23: Power Harness (78) Wire Identification




FIG. 24


## Suggested Replacement Parts

| Part   | Description  |
|--------|--|
| 24K984 | DRYER, desiccant   |
| 24K983 | SWITCH, motor or heater power, with circuit breaker                          |
| 101078 | Y-STRAINER   |
| 26A349 | KIT, filter, replacement (2 pack)  |
| 26A350 | KIT, filter replacement (10 pack)  |
| 15D909 | ELEMENT, air filter, 5 micron; polypropylene                                 |
| 239914 | VALVE, recirc/spray; includes seat and gasket                                |
| 24L002 | POTENTIOMETER, control knob  |
| 24K999 | TRANSDUCER, pressure   |
| 24L006 | PUMP, displacement; fits either side   |
| 249855 | REPAIR KIT, displacement pump; includes seals, balls, bearings, intake seat) |
| 24T974 | O-RING, tank lid   |

## Accessories

| Part   | Description        |
|--------|--------------------|
| 24E727 | Probler Recirc Kit |
| 24U342 | Lift Ring Kit      |

## Dimensions



# Technical Data

| Reactor E-10hp   | US   | Metric             |
|--|--|--------------------|
| Maximum fluid working pressure                         | 3000 psi   | 20.6 MPa, 206 bar  |
| Maximum spray pressure: 120 V                          | 2200 psi   | 15.2 MPa, 152 bar  |
| Maximum spray pressure: 230 V                          | 2500 psi   | 17.2 MPa, 172 bar  |
| Maximum fluid temperature                              | 170°F  | 77°C               |
| Maximum ambient temperature                            | 120°F  | 48°C               |
| Maximum output   | 1 gal./min   | 3.8 liters/min     |
| Output per cycle (ISO and RES)                         | 0.0038 gallons/cycle   | 0.014 liters/cycle |
| Air inlet  | 1/4 in. quick-disconnect industrial type pin fitting   |                    |
| Air outlet   | 1/4 npsm(m)  |                    |
| Overpressure relief                                    | Recirc/Spray valves automatically relieve excessive fluid pressure back to supply tanks  |                    |
| Gun compressed air requirements                        | Fusion Gun (purge air and operating air): 4 scfm (0.112 m <sup>3</sup> /min)   |                    |
| Maximum hose length                                    | 105 ft   | 32 m               |
| Tank capacity each (nominal)                           | 6 gal.   | 22.7 liters        |
| Weight (empty)   | 239 lb   | 108 kg             |
| <b>Recommended Mix Chamber Sizes</b>                   |  |                    |
| Fusion <sup>®</sup> Air Purge                          | 000, AW2222 (00 and 01 at reduced spray pressure)  |                    |
| Probler <sup>®</sup> P2                                | AA (00 and 01 at reduced spray pressure)   |                    |
| <b>Electrical Requirements</b>                         |  |                    |
| 120 V  | 100-120VAC, 1 phase, 50/60 Hz, 3840 W; requires two separate, dedicated 20 A circuits. Full load peak amperage 16 A per circuit. |                    |
| 230 V  | 200-240VAC, 1 phase, 50/60 Hz, 5520 W; requires two separate, dedicated 15 A circuits. Full load peak amperage 12 A per circuit. |                    |
| <b>Generator Size</b>                                  |  |                    |
| 120 V  | 5000 W minimum   |                    |
| 230 V  | 7500 W minimum   |                    |
| <b>Heater Power</b>                                    |  |                    |
| 120 V  | 3000 W during recirculation, 2000 W during pressure spray mode   |                    |
| 230 V  | 4000 W during recirculation, 2760 W during pressure spray mode   |                    |
| <b>Sound Pressure</b>                                  |  |                    |
| In fast recirculation mode                             | 71.3 dB(A)   |                    |
| Measure at 2500 psi (17 MPa, 172 bar), 1 gpm (3.8 lpm) | 85.6 dB(A)   |                    |
| <b>Sound Power*</b>                                    |  |                    |
| In fast recirculation mode                             | 79.9 dB(A)   |                    |
| Measure at 2500 psi (17 MPa, 172 bar), 1 gpm (3.8 lpm) | 93.3 dB(A)   |                    |

| Reactor E-10hp                         | US  | Metric |
|--|---|--------|
| <b>Fluid Outlets</b>                   |   |        |
| ISO Side                               | -5 JIC male   |        |
| RES Side                               | -6 JIC male   |        |
| <b>Fluid Circulation Returns</b>       |   |        |
| ISO side                               | -5 JIC male   |        |
| RES side                               | -6 JIC male   |        |
| <b>Hose Markings</b>                   |   |        |
| ISO side                               | Red   |        |
| RES side                               | Blue  |        |
| <b>Wetted Parts</b>                    |   |        |
| Wetted parts on all models             | Aluminum, stainless steel, carbon steel, brass, carbide, chrome, chemically resistant o-rings, PTFE, ultra-high molecular weight polyethylene |        |
| <b>Notes</b>                           |   |        |
| * Sound power measured per ISO-9614-2. |   |        |

All other brand names or marks are used for identification purposes and are trademarks of their respective owners.

# Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

**THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.**

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

**GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO.** These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

## **FOR GRACO CANADA CUSTOMERS**

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

# Graco Information

**For the latest information about Graco products, visit [www.graco.com](http://www.graco.com).**

**For patent information, see [www.graco.com/patents](http://www.graco.com/patents).**

**TO PLACE AN ORDER, contact your Graco distributor or call to identify the nearest distributor.**

**Phone: 612-623-6921 or Toll Free: 1-800-328-0211 Fax: 612-378-3505**

*All written and visual data contained in this document reflects the latest product information available at the time of publication. Graco reserves the right to make changes at any time without notice.*

Original instructions. This manual contains English. MM 332144

**Graco Headquarters:** Minneapolis

**International Offices:** Belgium, China, Japan, Korea

**GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA**

**Copyright 2013, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.**

[www.graco.com](http://www.graco.com)

Revision G, July 2017